

尺寸:82 X 82 mm
材料:120g 哑粉纸
工艺:四色印刷, 折页

X08 User Manual TRUE WIRELESS EARBUDS	Customer Service Tel: +1 (781) 678-8108 Mon. - Fri. (If you have any issue, please feel free to contact us, and we will reply within 48Hrs.) Packing List Earbuds X2 Charging case X1 Couple Eartips X 3 USB-C Charging CableX1 User Manual X 1 01	Product Overview 1.Charging Case 2.LED Power Display 3.USB C Charging Port 4.Touch Control Area 5.Earbud LED Light 6.Microphones 7.Charging Point 02	Specification Product Name: TWS IC: 28985-X08 Input: 5V=0.5A Model No.: X08 HVIN: X08 FCC ID: 2BV3D-X08 Battery Capacity: 470mAh 3.7V, 1.74Wh Wear Step1: Choose the comfortable eartips S M L Step2: Wear it in ear and adjust to a comfortable position (Please put the right and left headphones on the correct ear) 03	Power On Auto Power On: Open the charging case, earbuds will power on automatically. Manual Power On: Long tap on touch control area of one earbud for 2s, earbud will power on and earbud light will become blue. 04	Power Off Method 1 Put both earbuds into the charging case, and close the case earbuds will power off automatically. Method 2 (Note: This method just for earbuds are not yet paired with your device.) Long tap on either earbud for 5s, light on earbud will flash red, then earbud power off. 05	Pairing Stereo Mode 1. Open the charging case, earbuds will power on automatically, and then they will connect with each other, and waiting to pair with your phone. 2. Trun on the bluetooth of your phone and search "X08",choose "X08", earbuds will connect with your phone. Single Earbud Mode 1. Take one earbud(Left/Right) out from the charging case and close the case. 2. Trun on bluetooth of your phone and choose " X08 ",earbud will pair with your phone successful. 06	Phone Calls Control Answer / End Calls: Double tap on either earbud Reject Calls: Long tap on either earbud for 2s Note: The earbuds can be use individually or simultaneously. 07
Music Pause / Play: Tap once on either earbud Volume and Voice Assistant: Volume + : Long tap on right earbud Volume - : Long tap on left earbud Voice Assistant: Quick triple tap on right or left earbud Next / Previous Track: Previous Track: Double tap on left earbud Next Track: Double tap on right earbud 08	Charging Earbuds Charging Put both earbuds into charging case and close case, earbuds are being charged and led power display on case will move. Charging for the case. Method 1: Use USB C charging cable(provided) to connctet an adapter (not provided) your charging case. Method 2: Put the charging case on wireless charger(not provided). Please keep Led power display facing up, case can be charged automatically. Method 2 Method 1 Note: for method 2,please place the charging case on the wireless charger until the LED power display flashes,which indicates case is being charged. 09	Safety Instruction 1. Using earphone at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at times for your safety. 2. Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds. 3. Do not use earphone in thunderstorm weather, the earphone may not work properly in the condition, and increase the risk of bring hit by lightning. 4. Earphone may not work properly under high temperature or high humidity conditions. Do not use any corrosive cleaner/oil to clean the earphone. 5. If the earphone comes in contact with liquids, quickly wipe away. 6. If submersed in water, do not turn the earphone on until completely dried. (Tips: liquid submersion voids the warranty.) 7. Keep the earphone and packaging out of reach of children. 8. Please use the original charging cable provided by the earphone manufacturer for charging and choose the right adpter. 10	FAQ Q: Why these earbuds can not pair with my mobile phones? A: 1. Please make sure the earbuds are full charged and power on. 2. Please make sure the bluetooth of your phone is trun on. 3. If above 2 points have no problem, please put earbuds into the case again and close the case, hold on for 1min, then open the charging case and reconnect earbuds with your phone. Q: Why does the music cut in or cut out? A: First, please do not let the distance between these earbuds and your phone more than 33 feet(without obstacle).If the distance less than 33 feet, Please note 2 tips as below: 1. Please make sure there is no obstacle between the earbuds and your device. 2. Please make sure there is no Microwave oven/Wifi transmitter around you, which are more likely to produce electromagnetic interference and result in signal interruption. Q: Why does the earbuds can not be chagrred and not disconnected with my phone even earbuds are put into case and I have closed the case? A: Please make sure the charging case are not in low battery, if the charging case are in low battery, earbuds can not be charged and not disconnected even though they are in case. So, please use the type-c cable to charge the case fully. Q: How to contact Our Customer service? A: We offers one year replacement warranty, if there is any issue with your earbuds, please don't hesitate to contact us,we will reply within 24 hours and resolve it 100%. 11	Battery Warning Using the wrong battery can cause fire and other hazards (for example,in the case of some lithium battery types) 1. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. 2. Do not leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas 3. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas. 12	ISED Warning --- Reorient or relocate the receiving antenna. --- Increase the separation between the equipment and receiver. --- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --- Consult the dealer or an experienced radio/TV technician for help. 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 13	Caution DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS The symbol indicates DC voltage RECYCLING (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance. Le présent appareil est conforme Après examen de ce matériel aux conformité ou aux limites d' intensité de champ RF, les utilisateurs peuvent sur l' exposition aux radiofréquences et la conformité et compliance d' acquérir les informations correspondantes. 14	Notes The device is low power device, it can meet the requirement of the RF exposure. This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment. This product can be used across EU member states. The device is low power device, it can meet the requirement of the RF exposure. NOTES: 1. High Sound Pressure 2. Hearing Damage Risk 3. Do not listen at high volume levels for long periods. CE Made in China 15