

品名: 说明书
尺寸: 105*135mm
材质: 105G双胶
双面单色印刷, 风琴折

4C+1专

Model: BS12308

BUGANI

BUGANi Brief Go

USER MANUAL

PORTABLE BLUETOOTH SPEAKER

PRODUCT OVERVIEW

1. Volume Down / Previous Song
2. Play/Pause
3. Volume Up / Next Song
4. Bluetooth mode
5. Bluetooth Broadcast mode
6. USB-C
7. Power On/Off/Indicator light

CHARGING

Don't plug the cable in when your speaker and the charging port are not completely dry. Leave your speaker in a dry area with some airflow to let the port air dry naturally.

POWER ON / OFF

Hold down the power button for 2 seconds to power on. Hold down the power button again for 2 seconds to power off.

BLUETOOTH CONNECTION

When first used and turned on, the speaker will automatically enter a pairing mode for connection. If the Bluetooth device is already connected, press the "X" button to disconnect the current connection and connect with other devices. The speaker will automatically enter pairing mode if it is not connected to a Bluetooth device. When pairing, enable the Bluetooth function of the phone and search for "BUGANi Brief Go" to connect. When the connection is successful, you will hear a prompt tone and the Bluetooth indicator will turn from blinking to long on.

MUSIC CONTROL

Short Press the "▶" button to play or pause music. Long press the "◀" button to go to the next song. Long press the "◀" button to go to the previous song.

BLUETOOTH BROADCAST MODE

Set one "Brief Go" as the main speaker, and you can connect it to more than 100 auxiliary "Brief Go" speakers to control their functions. 1.First, connect one of the "Brief Go" speakers to your Bluetooth device (such as a mobile phone) as the main speaker and play music. 2.Press the "△" button twice on the main speaker and other "Brief Go" speakers to enter Bluetooth broadcast connection mode and connect automatically. 3.After successful connection, the green LED indicator on the main speaker will continue to flash, and the green LED indicator on the auxiliary speaker will change from flashing to long light.

BUTTON CONTROLS

Press and hold for 2 seconds	Turn On/Off
Short press	Volume down
Long press	Previous song
Short press	Play/Pause/Answer a call/End the call
Long press	Reject a call
Double click	Enable/disable the voice assistant
Short press	Volume up
Long press	Next song
Short press	Bluetooth connection/Disconnect
Press and hold for 5 seconds	Clear Bluetooth pairing list
Double click	Bluetooth broadcast connection / Disconnect

RESET

When the speaker is turned on, press and hold the "⏮" button for 8 seconds.

BUGANI LIMITED WARRANTY

BUGANI Corporation ("BUGANI") warrants your product against defects in materials and workmanship when purchased directly from BUGANI or a BUGANI authorized reseller. This warranty is extended only to the original end-use purchaser or the person receiving the product as a gift and shall not be extended to any other person or transferee. The warranty is valid from the date of retail purchase for a period of 1 year. BUGANI will provide the Warranty Services in accordance with the relevant laws and regulations of local government. This warranty does not cover defects or damage arising from improper use or maintenance, normal wear and tear, commercial use, accident or external causes. Unauthorized repair, modification or customization of your product voids this warranty. For warranty service on covered defects during the warranty period, contact BUGANI using the contact information at world-wide. Prior to providing warranty service, BUGANI may require you to provide proof of purchase details, including but not limited to a receipt or sales invoice. For more information, please visit www.bugani-global.com. Please contact: care@bugani-global.com

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off, and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and the receiver. - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio / TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2BAYX 8512308

Model: BS12308

BUGANI

BUGANi Brief Go

用户手册

本产品由中国平安保险公司承保
便捷蓝牙音响

产品概述

1.音量减/上一曲
2.播放/暂停
3.音量加/下一曲
4.蓝牙模式
5.蓝牙广播模式
6.USB-C充电接口
7.电源开/关/指示灯

充电

当音响充电接口未完全干燥时，请勿插入充电线。将音响放在有空气流通的干燥区域，让充电口自然风干。

开机/关机

按住电源开 / 关按键 2 秒即可开启音响。再次按住电源开 / 关按键 2 秒即可关闭音响。

蓝牙配对

首次使用并开机时，音响将自动进入配对模式。如已连上蓝牙设备，短按 "X" 键，即可断开当前连接以便与其它设备进行配对。如没有连上蓝牙设备，音响也会自动进入配对模式。配对时，启用手机的蓝牙功能，搜索 "BUGANi Brief Go" 进行连接，连接成功后你会听到提示音，蓝牙白色指示灯由闪烁变为长亮。短按 "△" 键调低音量。短按 "△" 键调高音量。短按 "△" 键。结束通话：短按 "▶" 键。

音乐控制

短按 "▶" 键播放或暂停音乐。长按 "▶" 键转到下一首歌曲。长按 "▶" 键转到上一首歌曲。

音量控制

短按 "▶" 键调低音量。短按 "▶" 键调高音量。

通话控制

接听来电：短按 "▶" 键。拒接来电：长按 "▶" 键。结束通话：短按 "▶" 键。

语音助手

已连接蓝牙状态，双击 "▶" 键启用 / 关闭语音助手。

蓝牙广播模式

设置一个 "Brief Go" 为主音响，可连接 100+ "Brief Go" 副音响控制其功能。1. 首先，将其中的一个 "Brief Go" 音响连接到您的蓝牙设备（例如手机）作为主音响并播放音乐。2. 双击主音响和其它 "Brief Go" 音响上的 "△" 键，进入蓝牙广播连接模式并自动连接。3. 连接成功后，主音响上的绿色 LED 指示灯继续闪烁，副音响上的绿色 LED 指示灯由闪烁变为长亮。成功进入蓝牙广播模式后，您可以通过控制主音响关闭所有音响，调节音量等。您可以分别关闭每个副音响的电源。如要退出蓝牙广播模式，请再次双击任意音响上的 "△" 键。

按钮控制

长按2秒	开/关机
短按	调低音量
长按	上一曲
短按	播放/暂停/接听电话/结束电话
双击	拒接电话
短按	调高音量
长按	下一曲
短按	蓝牙连接/断开
长按5秒	清除设备配对记录
双击	蓝牙广播连接/断开

复位

在开机状态下，长按 8 秒 "⏮" 键至音响重新开机，即可复位音响。

注意

1. 不建议未经许可私下更换电池。
2. 电池 [电池组或电池组合] 不得暴露在诸如日照、火烤或类似过热环境中。

产品规格

品牌	BUGANI	型号	BS12308	颜色	黑色	尺寸	105*135mm	重量	150g	功率	5W	蓝牙版本	5.0	充电接口	USB-C	充电时间	2-3小时	待机时间	10-12小时	防水等级	IPX5	保修期	1年
----	--------	----	---------	----	----	----	-----------	----	------	----	----	------	-----	------	-------	------	-------	------	---------	------	------	-----	----

本产品符合CE、FCC、RoHS、REACH、PSE、CCC、UL、EN、GB、GB/T、GB 4943.1、GB 4943.2、GB 4943.3、GB 4943.4、GB 4943.5、GB 4943.6、GB 4943.7、GB 4943.8、GB 4943.9、GB 4943.10、GB 4943.11、GB 4943.12、GB 4943.13、GB 4943.14、GB 4943.15、GB 4943.16、GB 4943.17、GB 4943.18、GB 4943.19、GB 4943.20、GB 4943.21、GB 4943.22、GB 4943.23、GB 4943.24、GB 4943.25、GB 4943.26、GB 4943.27、GB 4943.28、GB 4943.29、GB 4943.30、GB 4943.31、GB 4943.32、GB 4943.33、GB 4943.34、GB 4943.35、GB 4943.36、GB 4943.37、GB 4943.38、GB 4943.39、GB 4943.40、GB 4943.41、GB 4943.42、GB 4943.43、GB 4943.44、GB 4943.45、GB 4943.46、GB 4943.47、GB 4943.48、GB 4943.49、GB 4943.50、GB 4943.51、GB 4943.52、GB 4943.53、GB 4943.54、GB 4943.55、GB 4943.56、GB 4943.57、GB 4943.58、GB 4943.59、GB 4943.60、GB 4943.61、GB 4943.62、GB 4943.63、GB 4943.64、GB 4943.65、GB 4943.66、GB 4943.67、GB 4943.68、GB 4943.69、GB 4943.70、GB 4943.71、GB 4943.72、GB 4943.73、GB 4943.74、GB 4943.75、GB 4943.76、GB 4943.77、GB 4943.78、GB 4943.79、GB 4943.80、GB 4943.81、GB 4943.82、GB 4943.83、GB 4943.84、GB 4943.85、GB 4943.86、GB 4943.87、GB 4943.88、GB 4943.89、GB 4943.90、GB 4943.91、GB 4943.92、GB 4943.93、GB 4943.94、GB 4943.95、GB 4943.96、GB 4943.97、GB 4943.98、GB 4943.99、GB 4943.100