

JPYS

GT630S

User Manual


2-in-1 True Wireless Earbuds



Clip-On: GT630S | **FCC ID:** 2BV7S-GT630S
In-Ear: GTM06 | **FCC ID:** 2BV7S-GTM06
Rear Ports: USB-A + USB-C

Panel 1 of 12

1 Product Overview



Rear Ports
USB-A + USB-C
Both charging ports are on the back.

Charging Case
Display / Touch Area

Panel 2 of 12

2 Specifications


Product Model	GT630S
Pairing Names	GT630S / GTM06
Earbud Types	Clip-On GT630S; In-Ear GTM06
Earbud Batteries	GT630S 30mAh; GTM06 25mAh
Case Battery	600mAh
Input	5V DC 250mA
Charging Time	About 2 hours
Charging Ports	USB-A + USB-C on rear
Wireless Version	6.0
Speaker	12mm / 32 ohm
Working Range	Up to 15m / 49ft open area
Playback Time	GT630S up to 4h; GTM06 up to 3h
Compatibility	iOS / Android / Windows

Panel 3 of 12

3 Package & Rear Ports

Package Contents:

- Charging Case x1
- Clip-On Earbuds GT630S x1 Pair
- In-Ear Earbuds GTM06 x1 Pair
- USB-C Cable x1
- User Manual x1



USB-A and USB-C ports are located on the back of the charging case.

Charging cable included. Power adapter is not included.

Panel 4 of 12


4 Pairing & Power

1. Fully charge the case and both earbud sets before first use.
2. Open the charging case and remove the set you want to use. The earbuds power on automatically.
3. Turn on wireless connection on your phone and search for devices.
4. Select **GT630S** for the clip-on earbuds, or **GTM06** for the in-ear earbuds.
5. After the first connection, the same set reconnects automatically when removed from the case.
6. Return the earbuds to the case and close the cover to power off and recharge.

Reconnect: If pairing fails, place the earbuds in the case for 10 seconds, then remove and pair again.

Panel 5 of 12

5 Touch Controls



Control response may vary by phone model, operating system, media app, and call status.

Panel 6 of 12

- Power adapter not included.
- Use a standard 5V USB power source only.
- Charging input: 5V DC 250mA.
- Normal charging time: about 2 hours.
- Do not charge the product when ports are wet.
- Do not use chargers that exceed 5.5V output.
- Keep charging contacts clean and dry.
- If stored for a long time, recharge at least once per month.

Important: Stop use immediately if the battery area becomes hot, swollen, leaking, or damaged.

Not pairing: Return the earbuds to the case, wait 10 seconds, remove them again, and reconnect.

Only one side works: Put both earbuds back into the case, then remove both again.

Not charging: Check the USB cable and gently clean the charging contacts.

Low sound: Clean the earbuds and reduce the distance from your device.

No power: Charge the case and earbuds for at least 30 minutes before trying again.

Connection unstable: Keep away from strong RF interference sources and keep the phone nearby.

Reset tip: Remove the pairing record on your phone, place the earbuds back in the case, and pair them again.

GT630S: FCC ID:2BV7S-GT630S
GTM06: FCC ID:2BV7S-GTM06

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Important Safety Instructions

- Contains rechargeable Li-ion batteries.
- Do not disassemble, crush, puncture, short-circuit, or expose to fire.
- Do not expose to high temperature, moisture, or direct sunlight.
- Do not squeeze with heavy objects or treat the product violently.
- Keep out of reach of children. This product is not a toy.
- Stop using the product if it is damaged, leaking, swollen, or overheating.



Do not dispose of this product or its built-in batteries with household waste.

Follow local regulations for electronic waste and battery recycling. Do not incinerate, crush, or puncture batteries.

Customer Support:
370047527@qq.com

For Amazon orders, contact us through your Amazon order page or by using the support email above. Keep your proof of purchase for service reference.

Manufacturer:
Wuhan Jiangping Yisheng New Energy Co., Ltd.

Unified Social Credit Code:
91420115MAEBRGYW19

Address: Unit 3, Building 9, MAX Science and Technology Park, Chuanggu Third Road, Miaoshan Development Zone, Jiangxia District, Wuhan City, Hubei Province, China

Country of Origin: Made in China
Retain this manual for future reference.