



Instruction Manual

Battery Case

For iPhone 16 Pro Max

MODEL: DDC003

Instructions


Button Instructions

- **Press once** to activate the wireless charging and display the battery status.
- **Double-press** to turn off wireless charging.




Port Instructions

- **INPUT:** Connect to a power source to charge this device.




- **OUTPUT:** Can also be used to charge other electronic devices.



Smooth-sliding camera cover



Kickstand functions




Compatible with MagSafe accessories (Wireless Charger Excluded)

Note: Its built-in magnets are only for secure attachment, not for MagSafe charging.



Disassembly Instructions

As shown in the image, push out from the lens area.



Specifications

Input	5 V $\approx$ 3 A, 9 V $\approx$ 2 A
Output	Wireless Charging: 5 W / 7.5 W USB-C Output: 5 V $\approx$ 1 A
	Wireless + USB-C Simultaneous Output: 5 V $\approx$ 2 A
Battery Capacity	5000 mAh (3.87 V / 19.35 W)
Rated Capacity	2850 mAh (5 V $\approx$ 1 A)
Safety Protection	Over-voltage Protection, Over-current Protection, Over-temperature Protection, Under-voltage Protection, etc.

Important Safety Instructions

- Please fully charge this product before first use.
- When charging, please use certified chargers and cables that match the specifications of this product. Avoid using power supplies or chargers that are not approved by the manufacturer or do not meet quality standards, as this may result in fire hazards or personal injury.
- When charging this product or using it to charge other devices, ensure someone is present. After charging is complete or if not in use for a long time, please unplug the charger and cable.
- The recommended operating and storage temperature is 0°C-40°C (32°F-104°F). Do not use or store in high-temperature or humid environments.
- Keep the product away from open flames, high temperatures (such as direct sunlight), or enclosed high-heat environments; exposure to extreme heat or open flame may cause fire or explosion.
- If the battery is used in an environment with extremely low air pressure, it may explode or leak flammable liquids/gases; during use or transportation, please handle with care.
- If not used for a long time, it is recommended to store the product at about 50% charge in a cool, ventilated place; recharge and discharge at least once every 3 months to maintain battery health.
- The product may heat up during charging, which is normal; however, if abnormal heating, odor, smoke, swelling, or liquid leakage occurs, stop using it immediately and contact after-sales service.
- Do not disassemble, modify, or repair this product yourself; non-professional disassembly or incorrect assembly may cause fire, explosion, or personal injury.
- Avoid dropping, strong impact, or excessive force during use or transport, as these may damage the product and pose safety risks.
- Clean this product with a dry cloth; do not use harmful chemicals or solvents.
- When disposing of used batteries, separate batteries of different chemical types and follow local recycling and hazardous waste regulations; discharged batteries may cause fire or smoke.
- If battery replacement is needed, ensure the correct battery type is used; using the wrong type may risk explosion.
- Under normal use, battery capacity will decrease annually over time, which is a natural degradation of battery performance.
- The product, accessories, and user interface illustrations in this manual are for reference only; actual products may differ due to upgrades. Please refer to the actual product.



This symbol indicates that this product should not be disposed of as household waste and should be taken to appropriate recycling facilities for safe disposal.

FCC Warning Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 35°C or Incinerate.



Scan the QR code to check
the installation video



PRINTED WITH
SOY INK

V1.0 SKU-3001220