


Wireless Microphone

User Manual



1

1、Important Safety Information

Thank you for purchasing and using this product!
Please read the instructions carefully before using this product!
All safety precautions and operating instructions. Avoid improper use to prevent problems.
Please keep this manual and its safety and operation instructions properly for future reference.
Be alert to warnings - Please follow all the warnings on this equipment and the operation instructions.
Refer to the manual - Please follow all operation and usage instructions.

Warning

- .Warning - To reduce the risk of fire or electric shock, please do not expose this equipment to rain or moisture.
- .Warning - Only use the accessories specified by the manufacturer (such as dedicated power adapter, battery, etc).
- .Warning - The plug should be connected to the power cut-off device of this equipment and should always be in a usable state.
- .Warning - Do not listen too closely.
- .Warning - Do not listen for an extended period at high sound pressure levels.
- Danger - Prevent the equipment from falling and hitting the ground.
- Danger - Prevent the equipment from colliding with sharp corners.


Matters need attention:

Do not disassemble, drop, collide, squeeze or modify the battery.
Do not insert foreign objects into the battery, puncture the battery. Do not immerse the battery in water or other liquids.
Do not place the battery in a high-temperature environment to avoid internal short circuit, overheating, leakage, fire, or explosion.

Note: These maintenance service instructions are intended for use by qualified maintenance personnel only. Do not perform any maintenance without the necessary professional qualifications to avoid risks of damage and electric shock!

2


2、User Manual for Function Usage



- 1-Microphone: After the connection is successful, speak or sing into the microphone.
- 2-Digital display: After powering on, the LED numbers light up. The receiver automatically connects after being turned on, and remains constantly illuminated after the connection.
- 3-Volume+: When in use, short press + microphone volume.
- 4-Volume-: When in use, short press - microphone volume.
- 5-Power: Long press to turn on, activate the microphone power, and then long press again to turn off.
- 6-charging port: Connect to the TYPE-C port using a 5V/1A charger. When charging, the LED light turns red.

3

3、Interface Function



- ① Power: Long press to turn on, activate the microphone power, and then long press again to turn off.
- ②③ Microphone connection light: The microphone indicator lights up when connected and flashes when not connected.
- ④ Charging reminder: When charging the red light is on; when fully charged the red light goes out.
- ⑤ Battery Holder: Open the battery compartment correctly insert the 14500 battery, and then close the compartment cover to complete the battery insertion.
- ⑥ Charging part: TYPEC Charging part DC 5V/1A
- ⑦ 6.35 Audio head It has an interface a 6.35 audio socket. Once turned on and the microphone is activated, it can be used.


4、Specification and Parameters

Name:	Wireless microphone
Bandwidth:	2 MHz
Sensitivity:	-85dBm
Frequency:	2402-2480 MHz
SNR:	> 92dB
Reference input:	DC 5V/1A


Main Function:	Wireless microphone
	Singing karaoke
	Two-microphone duet
Operation Parameter:	Supply current: Type-C USB 5V
	Charging time: 3-4 hours
	Utility time: 7-8 hours

The above data were obtained through production testing. However, there may be slight discrepancies in actual usage due to differences in the objective environment and tool factors.

5、Product Display and Accessorise



Wireless Microphones*2



Receiver*1



User Manual*1



Type-C USB cable*1



Anti-slip Rings*2



Adapter*1