



Instruction Manual

Button instruction



Instructions for use



How to Successfully Connect Bluetooth?

1. Plug the handset cord into the main unit, then turn on the power switch.
2. Pair your phone with the mobile device named "BT-MSGPHONE". Once paired, it will automatically reconnect each time you power on.

Bluetooth Mode

Bluetooth pairing:

Switch to BT (as shown in the picture), activate the Bluetooth mode, and the mobile phone connects to the device via Bluetooth (BT-MSGPhone).

Volume adjustment:

The volume can be adjusted by "🔊+" / "🔊-":

🔊+: Volume + (When the volume is at its highest, a beeping sound will be produced)

🔊-: Volume -

Answering the phone:

When the phone receives a call in Bluetooth mode, the device will ring synchronously. You can pick up the receiver to answer the call, press the bronze button to hands-free, and put the receiver back to hang up the call.

FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, **which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.