

Instructions for Video Walkie Talkie



Power on: The main power switch on the side. Long press the power-on button on the panel for 2 seconds to turn it on and enter the main menu.



After power-on, according to the picture color, there are two models: "STA Model" and "AP Model". Only these two models can match normally to use the intercom function; identical models cannot pair with each other.

Visual Walkie-Talkie

After successful pairing, the screen will display "Our Side" and "Opponent's Side" screens. Press the "Left" or "Right" key to switch. To adjust the size of the "Our Side" screen, hold down the "Walkie-Talkie Key" and speak into the microphone, and the other party will be able to hear you. Release the "Walkie-Talkie Key" and you can also hear the other party's voice. Press the "Up" or "Down" key once in the picture-in-picture to adjust the volume.



Visual Walkie-Talkie

Photo and Video Recording

Short press the "Power Switch Key" to return to the main menu interface. Insert a memory card, press the left and right keys to select the "Photo" icon, then press the "Confirmation Key" to enter the imaging mode. The front camera is used for taking photos: Press the "Confirmation Key" once to take a photo, and the front camera will record before taking the photo. Long press the "Confirmation Key" for 2 seconds to start the video recording timer. During video recording, long press the "Confirmation Key" for 2 seconds to stop the current recording. In the imaging mode interface, press the "Right" key to switch between the front and rear cameras for taking photos and record



Front and Rear Dual Cameras

Picture and Video Viewing

Short press the "Power Switch Key" to return to the main menu interface. Insert a memory card, press the left and right keys to select the "Photo" icon, then press the "Confirmation Key" to enter the imaging mode. The front camera is used for taking photos: Press the "Confirmation Key" once to take a photo, and the front camera will record before taking the photo. Long press the "Confirmation Key" for 2 seconds to start the video recording timer. During video recording, long press the "Confirmation Key" for 2 seconds to stop the current recording. In the imaging mode interface, press the "Right" key to switch between the front and rear cameras for taking photos and recording videos.



Charging Port/Memory Card Slot

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (which can be determined by turning the equipment off and on), the user is encouraged to try to correct the interference by one or more of the following measures:

Note:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Warning (for Portable Devices):

This device has been evaluated to meet general RF exposure requirements. It can be used in portable exposure conditions without restriction.