


DATA COMMUNICATION STICK


SP-DCS-4G-A
SP-DCS-WL-A




1 Installation Preparation

WIFI Module (Model: SP-DCS-WL-A)


- Step 1: Connecting the tail end of the DCS to the head of the antenna.
- Step 2: Insert DCS into the DONGLE terminal and tighten it to ensure it is secure.




Step 1




Step 2




Step 1



Step 2



Step 3



Step 4

4G Module (Model: SP-DCS-4G-A)

- Step 1: Remove the protective cover of DCS and insert the SIM card.
- Step 2: Install the waterproof cover of DCS.
- Step 3: Connecting the tail end of the DCS to the head of the antenna.
- Step 4: Insert DCS into the DONGLE terminal and tighten it to ensure it is secure.

2 System Commissioning

2.1 Installing the App

Method 1


Download the "SafePOWER APP"
from the app store:

- App Store (IOS)
- Google Play

2.2 System Debugging

For more information on using the SafePOWER APP, please refer to the user manual "SafePOWER APP".
For system configuration and debugging, please refer to the user manual "SafePOWER Local Debugging APP".

3 Introduction of Indicator Lights



Indicator	Status	Description
POWER	ON	Power ON
	OFF	Power OFF
NET	Solid Green	Connected to the server
	Flashing	Connecting to the server
	OFF	Disconnected from the server
COM	Solid Green	Normal communication with inverter
	Flashing	Communicating with the inverter
	OFF	Communication with inverter failed

* Reset Button:

Press 2 times to restart,
Press 4 times to restore factory settings (Within 1 second between pressing).

Product information is subject to change without notice.

© 2024 1321 W Foothill Blvd, Azusa, CA 91702

6.2.51.18.00136
QI_SP-DCS-4G(WL)-
A_V1.1-202412_EU



www.safepowert.com

1321 W Foothill Blvd, Azusa, CA 91702

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ISED Warning

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with Innovation, Science and Economic Canada's radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux flux RSS exemptés de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne peut pas causer d'interférences.
2. Ce dispositif doit accepter toute interférence, y compris celle qui peut provoquer un fonctionnement indésirable du dispositif.

Cet équipement est conforme aux limites d'exposition au rayonnement d'innovation, sciences et développement économique Canada établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.