


EEKONTZ™ ET-JH09




Quick Start Guide
WIRELESS OVER-EAR HEADPHONE



1. ANC button
2. Volume up button, next song
3. Volume down button, previous song
4. Multi-function button (MFB)
5. Indicator light
6. 3.5mm Audio Jack
7. USB-C charging port
8. MIC

Charging

Please fully charge the headset before using this device. This device can be charged through the USB-C interface, and the red light will remain on and turn off when fully charged



Power On/Off

In the power off state, long press the MFB button for 3 seconds to turn on the headset, the white light flashes quickly, and the system will sound at the same time.

In the power on state, long press the MFB button for 5 seconds to turn off the headset, the red light is on for 2 seconds, and the system will sound at the same time.

Pairing

In the power off state, long press the MFB button for 3 seconds, the white light flashes quickly, and the system will sound at the same time. For new device connection, turn on the Bluetooth in your device and choose "ET-JH09" from the Bluetooth list to connect. After successful pairing, the white light keep on for 1 second and turn off

Music

Play/pause: short press the MFB button

Next song: connected phone status, long press the "+" button for 2 seconds

Previous song: connected phone status, long press the "-" button for 2 seconds

Volume Control

Turn down the volume: connected phone status, press the "-" button

Turn up the volume: connected phone status, press the "+" button

Call

Answer/hang up: short press the MFB button

Reject the call: long press the MFB button for 2 seconds

Cancel a call: when the caller does not answer, press the MFB button twice

Voice Assistant

Connected phone status, press the MFB button twice

Adult Mode

Connected mobile phone status. Press and hold the "+" and "-" button simultaneously for 1 second to turn on/off the adult mode

Dual Device Smart Connection

After connecting the first phone, turn off the headphones and disable Bluetooth on that phone

Turn on the headphones again and connect them to a second phone. After successful connection, re-enable Bluetooth on the first phone and tap "ET-JH09" to reconnect

Reset

When the headphones are powered on, quickly press the MFB button five times. This will clear the pairing records between the headphones and the mobile phone, and then turn off the device

Low Battery

The red light flashes slowly

Low Power Shutdown

The red light is on for 2 seconds

Responsible for your hearing

To avoid hearing loss, turn down the volume of the music player before wearing headset. After putting on the headset, slowly adjust the volume to a suitable level.

The unit of measurement for noise is (db). Long-term exposure to 85db or higher noise environment may cause hearing loss gradually. Monitor usage; hearing loss is the result of too much noise and time. The louder the sound, the more time to reduce exposure to noise. The softer the voice, the longer you can listen. Please visit the Consumer Electronics Association website (www.ce.org) to learn how to establish a safe listening level and review other important safety guidelines. For important information on how to prevent noise-induced hearing loss (NIHL) and a complete list of what noise can cause hearing loss, please refer to the website of the Foundation for the Study of the Hearing Impairment: www.drf.org.

Battery usage note

- There is an explosion risk if the battery is not replaced properly. Batteries can only be replaced with batteries of the same type or equivalent. It is not recommended to replace the battery without permission, but it can be returned to the manufacturer for replacement.
- The cell [battery pack or battery pack and] shall not be exposed to conditions such as sunlight, fire or similar overheating.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and the receiver.
 - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio / TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received. Including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2BVFDD-ET-JH09

75*95mm 105g双铜 风琴4折 单色印刷