


Product Quick Start Guide
— FOLD M1 Base

Please read this guide before using the product and retain it for future reference


Product Appearance



Product Specifications


Model	M1	Color	White/ Brilliant Orange/ Light Pink
Battery	400mAh	Weight	38.5g
Voltage	5V	Storage	32GB
Bluetooth	Bluetooth5.3	Port	Type-C
Microphone	Multi-microphone Noise Cancellatio	Speaker	Stereo Dual Speakers
Video Resolution	1K	Video Codec	H.265/H.264
Protection Rating	IP68		

Volume Up, Power Button / Volume Down




When powered off: Long press the Power Button / Volume Down for 2 seconds to power on.
Voice prompt: "Power on. Bluetooth connecting."
When powered on: Long press the Power Button / Volume Down for 2 seconds to power off.
Voice prompt: "Power off."
When powered on (Bluetooth disconnected): Short press the Power Button / Volume Down or Volume Up to check battery level. Voice prompt: "High battery." / "Medium battery." / "Low battery." / "Insufficient battery, please charge."
When powered on (Bluetooth connected): Short press the Power Button / Volume Down to decrease volume. Short press Volume Up to increase volume.

Bluetooth Pairing




When the device is powered off, long press the Power Button. Upon hearing the voice prompt "Power on. Bluetooth connecting.", the device enters pairing mode. At this time, open your phone's Bluetooth settings, select and connect to the Bluetooth device named "MozinFoldM1 XXXX". You will hear the voice prompt "Bluetooth connected.", indicating a successful pairing.
(Please ensure that your phone's Bluetooth function is enabled and that you are within a range of 10 meters from the Bluetooth Headphones.)

Multi-function Button




During music playback: Short press -- Pause/Play music; Double press -- Next track; Triple press -- Previous track.
During an incoming call: Short press -- Answer/End the call.

Video Recording Function



Start Recording: Press the Camera Open/Close Key. The camera pops out, entering video recording mode. A voice prompt will say: "Recording started. Please do not close the recording abruptly."
Stop Recording: Manually close the camera. The system will automatically stop recording, and a voice prompt will say: "Recording ended."

LED Indicator



The Headphones has a built-in lithium-ion battery and supports charging via the Type-C port.
When charging, the Status Indicator shows a solid red light, indicating that charging is in progress.
When fully charged, the Status Indicator changes to a solid green light.
When the battery is low, the Status Indicator shows a flashing red light.
When the camera is open, the Camera Recording Indicator shows a solid green light.

Video Playback

Please perform the following operations when the Headphones is powered off or not recording.
Viewing on a Computer: Use a Type-C cable to connect the Headphones to your computer. The Headphones will enter USB drive mode. You can find the recorded video files by navigating to USB Drive > M1 > Videos.
Viewing on a Phone: Use a Type-C OTG cable to connect the Headphones to your phone. You can then access the Headphones's storage from your phone. The video storage path is M1 > Videos.

Packaging List

Mozin Fold M1 Headphones ×1	OTG Cable ×1	Quick Start Guide ×1

Declaration

Important Notice:
This product is equipped with audio and video recording capabilities. Please strictly comply with relevant national laws and regulations when using it, and respect the privacy rights and legitimate interests of others. Users shall bear full responsibility for any infringements or legal consequences resulting from their violation of laws. Our company assumes no legal liability.
Product Statement:
As our company is committed to the continuous optimization and technological improvements of our products, the content, specifications, or parameters contained in this Quick Start Guide may have slight discrepancies with the actual product. Please refer to the physical product received and the latest system interface for the most accurate information. This guide is for reference only and may be updated without prior notice.

Please read this guide before using the product and retain it for future reference

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.