Uvital

Vital Choices Vital Connections

# UV-8022-KBT

## User Manual

Corded Phone for Landline

## Congratulations

Before using your new corded landline telephone, please take a moment to review the Important Safety Information on the first page of this manual.

This manual contains all the necessary instructions for feature operations and troubleshooting to ensure the proper installation and functioning of your Uvital product. We encourage you to thoroughly review it for the best user experience.

For support, shopping, and everything new at Uvital, please visit our website at www.uvitaltop.com or contact us via email at support@uvitaltop.com.

**★Email: support@uvitaltop.com**

**★WhatsApp: +86 18028731279**

**WhatsApp**

Thank you for choosing Uvital!



## Phone Overview



① Handset Cord
② Handset
③ Numeric Keys(0-9),＊,#
④ Speakerphone
⑤ Redial Key
⑥ Switch On and Off
⑦ Handset Cord Jack
⑧ USB Charging
⑨ Battery Compartment



## Introduction

Welcome to the UV-8022-KBT user manual. This guide will help you set up and use your new landline telephone easily and effectively. Please read all instructions carefully before use.

1. Charging Way: USB charging
2. Battery Charging Current: 500mA
3. Working Mode:
(1) Music mode (idle mode)
(2) Handset mode (pick up the handset to enter)
(3) Speakerphone Mode (press Speakerphone button to enter)
5. Bluetooth Sound Volume Switch: In idle mode, the single point * key is volume +, and the single point # key is volume -
6.Key Prompt Tone:
(1) Chinese voice
(2) English voice
(3) DTMF key tone
7. Chinese and English Language Switching: Press and hold the * key to switch



8. Switch between Key Tone and Voice: double-click # key to switch

## Box Contents

When you open the box, you should find the following items:
1x Phone Base
1x USB Charging Cable
1x Handset
1x Handset Cord (Coiled)
1x User Manual

## Installation

### Setting Up Your Phone

1. Place your phone on a flat surface.
2. Connect the coiled cord to the base unit (the slot at the bottom of the landline).

### Bluetooth Connection

1. Press the power button at the bottom of the telephone to turn it on (voice prompt: “Power On”).
2. Turn on Bluetooth on your phone and select “LCS PHONE” to connect (voice prompt: “Connected”).



3. If you try to connect the device three times but fail, you will enter the waiting connection state. If there is no device to connect within 2 minutes, it will enter the low-power mode. Press any key or lift the machine to wake up the device.

### Receiving a Call

1. Pick up the handset when the phone rings.
2. When you finish the phone call, put the handset back on the phone base.

### Handset Mode

1. Lift the handset to enter handset mode, then dial the number to start the call.
2. Place the handset back to hang up during the call.
3. During the call, press the speakerphone button to switch to speakerphone mode; you can place the handset on the base to continue the call, and press the speakerphone button again to end the call.

### Speakerphone Mode

1. Press the speakerphone button to enter speakerphone mode and dial the number to start the call.



2. Once connected, you can talk hands-free; Press * or # to adjust the volume.
3. Press the speakerphone button again to end the call.
4. Lift the handset to switch to handset mode, and place it back to automatically end the call.

### Redial Last Number

Pick up the handset, then press REDIAL button when you hear the dialing tone, the last phone number will be dialed out automatically.

### Audio Playback

When the device is idle, you can use the device's speakerphone button to play audio. When the call is in, press the speakerphone button or the handle is lifted, the audio playback is paused. After the call ends, playback will automatically resume. You can adjust the volume on the base unit or by using the * or # keys.



## Troubleshooting Guide

### No Function

1. Unplug the phone.
2. Disconnect all cords.
3. Reconnect the cords securely.

### No Ringing or Dial Tone

1. Check the connection between the base unit and the wall socket.
2. Ensure the handset is connected to the base unit properly.
3. Verify that the telephone line is working by connecting another device to the wall socket.

### One Ring Only

Check if there are other devices connected to the same line. Remove any parallel units if necessary.

## Important Safety Information

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:



1. Read and understand all instructions before use.
2. Follow all warnings and instructions marked on the product.
3. Unplug the product from the wall outlet before cleaning. Use a slightly damp cloth for cleaning; avoid liquid or aerosol cleaners.
4. Do not use this product near water or in damp locations.
5. Place the product on a stable surface to prevent falls and damage.
6. Ensure proper ventilation. Do not block the ventilation slots on the telephone base or handset.
7. Do not place this product near heat sources such as radiators or in areas without proper ventilation.
8. Protect the telephone line cord from damage. Do not place it where it can be stepped on or pinched.
9. Never insert objects into the product's openings, as they may contact dangerous voltage points or cause short circuits.
10. Do not open the product yourself, as this may expose you to dangerous voltages or other risks.



11. Do not overload wall outlets or extension cords.
12. Avoid using the telephone during electrical storms to minimize the risk of electric shock.

## Environmental Information

This symbol means that your inoperative electronic appliance must be collected separately and not mixed with the household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste.

**Help us protect the environment in which we live!**

## Regulatory Compliance

This device complies with part 15 of the FCC Rules.Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.



- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This product is CE marked and fully complies with all applicable EU legislation.

## After-Sales Service

**★Email: support@uvitaltop.com**

**★WhatsApp: +86 18028731279**

**WhatsApp**