


MINISO

MT01-TW501
Wireless In Ear Earphones



USER MANUAL


English

1. Safety Precautions and Warnings:

- Please control the volume and usage time of the product reasonably to avoid hearing damage.
- The battery should not be stored in a discharged state for more than three months to prevent damage.
- Regularly clean the product and the contacts of the charging case with a clean, dry cloth to prevent the product from failing to charge or power on due to accumulated dirt.
- This product contains a built-in, non-removable battery. Disassembly, modification, or self-replacement is strictly prohibited. Do not disassemble, stifle, crush, or throw it into fire. Stop using it immediately if the battery swells. Do not expose it to high temperatures or use it after immersion in water.
- This product contains small parts. Keep out of reach of children under 3 years of age. Small parts may pose a choking hazard. The charging cable poses a potential strangulation hazard.

2. Product Overview and Controls

- ① USB-C Charging Port
- ② Multi-Function Button
- ③ Earbud Status LED
- ④ In-ear Earbud
- ⑤ Case Lid
- ⑥ Charging Pin
- ⑦ Charging Case
- ⑧ Charging Case Status LED



3. Charging

- The device shall be charged using the included charging cable. The LED indicator flashes red while charging and turns solid red when fully charged.

4. Power on / Power off

- Upon opening the charging case and removing the earbuds, the device automatically powers on and enters pairing mode.
- The earbuds will power off automatically when placed in the charging case. If you need to force a shutdown, press and hold the button for 5 seconds.

5. Pairing

- Initial Pairing: enable Bluetooth via Settings -> Bluetooth, select "MINISO MT01" to pair. A confirmation tone will sound upon successful pairing.
- Automatic Re-connection: once paired, your device will automatically reconnect to that device whenever both are powered on and within range. If multiple paired devices are nearby, they will typically connect to the last device used.
- Switching Between Devices: on your current connected device, disconnect "MINISO MT01" from its Bluetooth menu or turn that device's Bluetooth off. They will automatically attempt to connect to the next available paired device. To connect to a new (unpaired) device, repeat the steps under Initial Pairing.

6. Music Control

- Play / Pause: Double-tap the button on either earbud.
- Next Track: Triple-tap the button on the right earbud.
- Previous Track: Triple-tap the button on the left earbud.
- Volume Up: Single-tap the button on the right earbud.
- Volume Down: Single-tap the button on the left earbud.

7. Call Control

- Answer / End Call: when there's an incoming call, double-tap the button twice to answer or end the call.
- Reject Call: press and hold the button for 1.5 seconds to reject the call.

8. Voice assistant

- Press and hold the button for 3 seconds to activate your device's voice assistant (e.g., Google Assistant on Android or Siri on iOS).

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.