



JA27

NOVA BUDS

WIRELESS EARPHONES



USER MANUAL

EN

SPECIFICATIONS

Wireless Version: 5.4

Wireless Distance: ≥ 10 m

Speaker Diameter: 13 mm

Battery Capacity Earphones: 2*30 mAh

Battery Capacity Case: 400 mAh

INSTRUCTIONS

Music

Pause/Play: Double-tap either multifunction touch control while playing.

Previous Track: Press and hold the left earphone's multifunction touch control for 1 second.

Next Track: Press and hold the right earphone's multifunction touch control for 1 second. When using a single earphone, press and hold to switch tracks accordingly.

Call

Answer: Double-tap either multifunction touch control when a call comes in.

Reject: Press and hold either multifunction touch control for 1 second when a call comes in.

Hang Up: Double-tap either multifunction touch control during a call.

Voice Assistant

Triple-tap the left earphone's multifunction touch control.

When using a single earphone, either the left or right earphone can be used.

Game mode

Triple-tap the right earphone's multifunction touch control to enable or disable Game Mode.

Reset

In pairing or connected mode, tap either multifunction touch control 5 times to reset. The orange indicator flashes 5 times. The reset is complete.

WARNINGS

- Do not disassemble, repair, or modify this product.
- This product contains a built-in rechargeable lithium battery. Do not dispose of it improperly or throw it into fire.
- Do not expose this product to excessive heat, direct sunlight, or open flames.
- Do not expose this product to rain, moisture, or liquids.
- Do not throw, drop, crush, or subject this product to strong impact.
- Do not use this product if it is damaged, deformed, leaking, or operating abnormally.
- Stop using this product immediately if it overheats, emits an unusual odor, or shows signs of malfunction.
- Keep this product out of the reach of children.
- Do not charge or use this product in environments with excessive heat or humidity.
- Dispose of this product and its battery in accordance with local regulations.

PRECAUTIONS

- Avoid listening at high volume levels for extended periods to protect your hearing.
- Use only the supplied or a compatible charging cable and power adapter.
- Ensure the charging contacts are clean and dry before charging.
- Clean this product with a soft, dry cloth. Do not use chemical cleaners or solvents.
- When not in use for an extended period, recharge the battery at least once every three months to help maintain battery performance.
- Store this product in a cool, dry place when not in use.
- Disconnect the charging cable after the battery is fully charged.
- Avoid wearing the earphones while sleeping to prevent accidental damage or injury.

Note:

The illustrations of the product, accessories, and user interface in this manual are for reference only. The actual product and functions may vary due to product updates.



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the Radio Equipment Directive 2014/53/EU, the EMC Directive 2014/30/EU, the RoHS Directive 2011/65/EU.



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. 2006/66/EC and its amendment 2013/56/EU (battery directive).

This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2BVOB-JA27



This product and - if applicable - the supplied accessories too are marked with the UKCA marking and comply therefore with the applicable statutory requirements of Great Britain.



IMPORTED BY / IMPORTATO DA: **MONSTERA S.R.L.**
VIA APPIA NUOVA 669 - 00179 ROMA ITALY
C.F. E P.IVA: 17270811007
DESIGNED IN ITALY MADE IN P.R.C.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. --
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.