


110mm

80mm

Mini Speaker Instruction



Set Contains:

- Mini Speaker, Type C cable, Instruction
- A 150mAh re-chargeable lithium battery

Charging Instructions:

This wireless speaker has a built-in rechargeable battery. To recharge, plug the Type C USB cable into the charging port. Plug the other end into port on your computer or other device made for USB charging. It takes 1-2 hours to fully charge the speaker. Once the speaker is fully charged the red LED will change to blue color. When the battery charge has depleted, the speaker will turn OFF automatically. It is recommended to fully charge the speaker before its first use.

Wireless Connection Instructions:

Turn on the wireless speaker by pressing and holding the POWER SWITCH button. Perform the audio pairing procedure your device uses. The speaker will show as "MINI SPEAKER" on your device. If it does not show on the list, check that it is not paired with any other devices and try again.

Noted

- The pairing mode will stay for 20 minutes until successfully paired, otherwise it will automatically turn off to save power.
- Please turn the speaker off if you don't use it!

80mm

Specifications :

- Input/Output: 5V/0.5A
- Wattage: 1.5W
- Frequency Range: 2402MHz~2480MHz
- Max Sound Pressure Level: <80dB 1KHz
- Power Supply: Built-in 402030 150mAh re-chargeable lithium battery.
- Battery Capacity: 150 mAh

WARNING:

- This is not a toy. Keep out of reach of children.
 - This product contains a 3.7V lithium battery.
 - Rechargeable battery is only to be charged under adult supervision.
 - Battery is not replaceable.
 - Do not dismantle or replace the battery.
 - It is recommended to use only the provided charging cable.
- Adapter Requirement 5V / 0.5A only (avoid multi-cables and fast charging cable and adapters)

- Do not play with the product while it is being charged in case potential safety hazards.
- Ensure that the battery is fully charged to optimize the user experience.
- After charging is complete, please promptly remove the charging cable and power source.
- When not in use for an extended period, please ensure that the battery has some charge to prolong its lifespan.
- Packaging has to be kept since it contains important information.

FCCinformation :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- (1) Product name : (C)SS MINI SPEAKER.
- Model NO: WIC#686684
- FCC ID: 2BVOS-WIC686684
- (2) Supplier :
- SELLER HELPER INC.
131217th Street #1298,
Denver, CO 80202
Sellerhelper@sellerhelper.top

ATTENTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



MADE IN CHINA