

User Manual

*For better use of this product.
Please read this instruction manual
carefully!

APP OPERATION INSTRUCTIONS

App-Download

Download the AI control app by scanning the QR code.



Connect and Play

Step 1

Turn on the toy and the phone Bluetooth.



Step 2

Tap Connect Toy in app to pair.



Features



Xfans



AI Novel



AI Image



Voice Clone



X-Game



Long-Distance



Video Sync



Voice Control



Remote

Scan for User Guides



01


OPERATION INSTRUCTIONS

Power On/Off + Vibration Function

- Press and hold the "⊙" button for 2 seconds; the indicator light will illuminate and it will vibrate once, entering standby mode.
- In standby mode, press the "⊙" button to cycle through 9 vibration modes.
- Press and hold the "⊙" button for 2 seconds to turn off all functions.


Clamping/Winding Function + Reset

- In standby mode, press the "⊙" button to cycle through 9 clamping/winding modes.
- Press and hold the "⊙" button to turn off the clamping/winding mode.
- Within 1 minute after power off, press the "⊙" button to perform a reset.



Display Screen

- When a button is pressed, the screen will display the corresponding power level/gear.




02

03

CHARGING INSTRUCTIONS


1. Before each charging, please clean and thoroughly dry the device.
2. When charging, the indicator light will flash; after charging, the indicator light will stay on.
3. Please use the charging cable provided.
4. Please use a matching charger to charge, an unmatched charger may affect the battery life or damage the product.

Note: The product cannot be used while charging.




04


CLEANING INSTRUCTIONS



The product is suitable for regular rinsing.



Dry with a towel and store properly after use.



Do not immerse.

WARNING

- This appliance is not intended for use by children or persons with reduced physical, sensory, or mental capabilities. To avoid electric shock, do not use the charger near water. Do not use on swollen or inflamed areas of skin. Discontinue use if discomfort occurs. Do not use on the neck area.

05

ATTENZIONE!

- Do not use massage oil or hand cream as lubricant.
- Avoid direct sunlight and prolonged exposure to high temperatures.
- The product must be stored in a clean and dry place.
- Keep out of reach of small children and minors.
- Some parts may cause choking.
- Do not use the product on damaged skin or areas with irritation.
- Avoid sharing the device with others, as this may lead to illness and infection.

WARRANTY

1-year warranty

Any attempt to open or disassemble the product will void the warranty.

If you have any quality or usage issues, please feel free to contact us.

Service Email: guxudo@gmail.com




Scan the QR code for tutorials, live support, or product inquiries.

06

ENCOUNTER ANY PROBLEM, PLEASE CONTACT THE SELLER THROUGH AMAZON.

METHOD 1



METHOD 2



07

User Manual

* Vielen Dank, dass Sie unser Produkt verwenden.
Bitte lesen Sie diese Bedienungsanleitung vor der Nutzung sorgfältig durch.
* ご使用前に、必ず取扱説明書をお読みください。


LADEHINWEISE/充電方法

1. Vor jedem Laden das Gerät reinigen und vollständig trocknen.
2. Beim Laden blinkt die Anzeigeleuchte; nach vollständiger Ladung leuchtet sie konstant.
3. Nur das mitgelieferte Ladekabel verwenden.
4. Verwenden Sie einen passenden Ladestecker – inkompatible Ladegeräte können die Akkulaufzeit beeinträchtigen oder das Produkt beschädigen.

Hinweis: Das Produkt kann während des Ladens nicht verwendet werden.

1. 充電前に製品を清潔にし、完全に乾燥させてください。
2. 充電中はインジケータが点滅し、充電完了後は点灯します。
3. 付属の充電ケーブルのみを使用してください。
4. 対応する充電器を使用してください。非対応品はバッテリー寿命や製品破損の原因となります。

注: 充電中は使用不可です。



APP-BEDIENUNGSANLEITUNG/アプリ操作説明

App-Download

Laden Sie die KI-Steuerungs-App durch Scannen des QR-Codes herunter.

Verbinden und Spielen

Schritt 1

Spielzeug und Handy-Bluetooth einschalten

Schritt 2

In App Spielzeug verbinden antippen zum Koppeln

App ダウンロード

QRコードをスキャンしてAI制御アプリをダウンロードしてください。


接続とプレイ

ステップ1

おもちゃとスマホのBluetoothをオンにする。

ステップ2

アプリで“玩具接続”をタしてペアリング。



01

BEDIENUNGSANLEITUNG/操作説明

Display

• Beim Drücken einer Taste zeigt der Bildschirm den entsprechenden Akkustand/Die entsprechende Stufe an.

Vibration 1-9 Stufen Akkustand

Beiß-/Schlängelmodus 1-9 Stufen

Ein-/Ausschalten + Vibrationsfunktion

- "◎" -Taste 2 Sekunden lang gedrückt halten; die Anzeigeleuchte leuchtet auf und es vibriert einmal (Standby-Modus).
- Im Standby-Modus durch Betätigen der "◎" -Taste zwischen 9 Vibrationsmodi wechseln.
- "◎" -Taste 2 Sekunden lang gedrückt halten, um alle Funktionen auszuschalten.

Beiß-/Schlängelfunktion + Zurücksetzen

- Im Standby-Modus durch Betätigen der "◎" -Taste zwischen Beiß-/Schlängelmodi wechseln (9 Stufen).
- "◎" -Taste gedrückt halten, um den Beiß-/Schlängelmodus auszuschalten.
- Innerhalb von 1 Minute nach dem Ausschalten kann durch Betätigen der "◎" -Taste ein Reset durchgeführt werden.

ディスプレイ

• ボタンを押すと、画面に対応するバッテリー残量/強度レベルが表示されます。

振動 1~9段階
バッテリー残量
咬合・蜿蜒 1~9段階

電源オン/オフ + 振動機能

- 「◎」ボタンを2秒間長押しすると、インジケータライトが点灯し、1回振動してスタンバイ状態になります。
- スタンバイ状態で「◎」ボタンを押すと、振動モード(9段階)が切り替わります。
- 「◎」ボタンを2秒間長押しすると、すべての機能がオフになります。


咬合・蜿蜒機能 + リセット

- スタンバイ状態で「◎」ボタンを押すと、咬合/蜿蜒モード(9段階)が切り替わります。
- 「◎」ボタンを長押しすると、咬合/蜿蜒モードがオフになります。
- 電源オフ後1分以内に「◎」ボタンを押すと、リセット機能が作動します。

02

WENN SIE EIN PROBLEM FESTSTELLEN, WENDEN SIE SICH BITTE ÜBER AMAZON AN DEN VERKÄUFER

METHODE 1



METHODE 2



06

問題がございましたら、AMAZONを通じて販売者にお問い合わせください。

方法1



方法2



07

REINIGUNGSHINWEISE/クリーニング方法



GARANTIE/保証

• 1 Jahr Garantie

Jeder Versuch, das Produkt zu öffnen oder zu zerlegen, führt zum Erlöschen der Garantie.
Bei Qualitäts- oder Nutzungsproblemen können Sie uns gerne kontaktieren.
Service-E-Mail: guxudo@gmail.com

• 1年間保証

製品を分解または改造した場合、保証は無効となります。
品質や使用方法に関するご質問がございましたら、お気軽にお問い合わせください。
サポートメール: guxudo@gmail.com



05

04

FCC Warning
15.19 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Warning Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.