


User Manual:



1. Long press Button I for 3 seconds to turn on. The blue indicator light will automatically flash.
2. Enable Bluetooth in setting on your cell phone and search for "J06" to pair, and the indicator light stops flashing after pair succeed.
3. Button I: Supports various camera apps such as phone camera/beauty camera, etc.
4. Button II: Supports all apps for video shooting such as TikTok/customize button.
5. Direction Keys: flip videos on TikTok up and down, left and right. Long press the up and down keys to adjust the volume and long press the left and right keys to switch songs.
6. Multi-function Button: click to pause/play when viewing TikTok video (double-click to like) or other video apps, long press to play/pause Music.
7. Power off: Long press the power I button for 3 seconds to turn off.

How to Set Up (Note for iPhone and iPad User)

1. Apple iOS 13.4 and above setting method: ①Bluetooth connect ②Screen auto-rotate lock ③Open Settings - Accessibility - Touch - Assistive Touch - turn it on ④For iOS 15 and above, simply connect for the first time to use. If the tracking sensitivity has been adjusted, return the dot to the default position.



2. For button II, you need to customize the controlling dot position. If shooting pictures and videos function invalid. Please enter the software shooting interface, long press Button II without releasing, and click the direction key to move the "dot" into shutter circle range of the software. You don't need to reset again unless you ignore the device.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)this device may not cause harmful interference, and

(2)this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.