

Key Functions

Click: OK

Long press: video like

Touch Move: Slow swipe to move cursor

Fast swipe to turn page

Click: Screen Off

Double click: screenshot

Long press: Power on/off

Click: Zoom In

Long press: Continuous Zoom In

Click: Zoom Out

Long press: Continuous Zoom Out

Click: iOS: Home

Android: Back

Double click: Previous Track

Long press: Play faster

Click: Battery Level

Double click: Play/Pause

Long press: Auto-likes

Quick swipe


Swipe up: Volume +

Swipe down: Volume -

Click: Tack a photo

Double click: Next Track

Long press: Toggle Fast/Slow Motion Mode



- 1.Power On/Off: Long press the "0" key to power on; the indicator light will flash. Release the key. To power off, long press the "0" key again; the red light will flash and then turn off.
- 2.Bluetooth Pairing:On your phone, open 'Settings' -> 'Bluetooth' and find the device 'J20'. Tap to connect and pair.
For iPhone users only: You need to additionally enable accessibility features:
① Go to (Settings -> Accessibility -> Touch -> AssistiveTouch) and turn on AssistiveTouch.
② Go to (Settings -> Accessibility -> Zoom) and turn on Zoom. After enabling, the screen will enlarge; to return to normal display, simply double-tap the screen with three fingers.
- 3.Page Navigation: Quickly slide your finger across the touch screen area to turn pages left, right, up, or down.
- 4.Cursor Control: Place your finger on the touch screen area and slide to move the cursor (move the mouse pointer; do not lift your finger from the touch screen).
- 5.Button Functions: Refer to the manual for detailed button function descriptions.

Button	Click	Double click	long press
0	Screen Off	screenshot	Power on/off
+	Zoom In	⊘	Continuous Zoom In
-	Zoom Out	⊘	Continuous Zoom Out
I	IOS: Home Android: Back	Previous Track	Play faster
O	Battery Level	Play/Pause	Auto-likes
II	Tack a photo	Next Track	Toggle Fast/Slow Motion Mode

Mouse Function Settings

(not needed for Android)

Settings

Accessibility

Touch

AssistiveTouch

AssistiveTouch

On

AssistiveTouch

On

AssistiveTouch

On

Zoom Function Settings

(not needed for Android)

Settings

Accessibility

Zoom

On

Zoom

On

Tips:
Screen will enlarge after enabling Zoom.Double-tap the screen with three fingers to restore normal display.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)this device may not cause harmful interference, and
- (2)this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.