

Portable Bluetooth Intercom Speaker

Sechoer 23



USER MANUAL

Product Diagram



1 Power button

2 3-in-1-button:volume up/down,PTT key

3 Channel key

4 Speaker mesh

5 Silicone plug:Type-C charging port

6 Speaker diaphragm

7 Press clip:Equipped with strap

Button Control

Button	Operation	Function
Music/Phone Call		
	Press and hold for 1s	On/Off
TAP 1 X		Play/Pause
TAP 1 X		Answer/Hung up the call
	Press and hold for 1s	Repeat call
+	Rotate clockwise	Volume up
-	Rotate counterclockwise	Volume down
Bluetooth		
	Search and pair with Sechoer23	
Power key	TAP 2X (Music paused)	Disconnect
PTT		
	TAP 2X	Turn On/Turn Off
PTT key	Long press	Transmit
	Then release	Receive

Set all devices to the same channel to start intercom.

Product Parameters

Model	Sechoer23
Bluetooth Version	5.4
Bluetooth Range	40m
Frequency Response	60Hz-20KHz
SNR	70dB
Talk Range	1.5km
Power Input	DC5V±0.7A
Play Time	>40h (70% volume)
Charging Time	3h
Battery capacity	1500mAh
Product Weight	140g

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference and
(2) this device must accept any interference received,

including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on,

Please user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation,in conjunction with any other antenna or transmitter.

WARNING

This equipment must not be installed and operated with certain other antennas,transmitters, or other equipment that may be harmful to the equipment or cause interference.

Service

Any questions welcome to contact us:

service@sechoer.com

Manufacturer

Shenzhen sechoer Technology Co., Ltd

3F A1 Zeda Industrial Zone, No. 26 Jianshan Road, Fubao Street, Baoan District, Shenzhen, Guangdong, China, 518000

便携式蓝牙对讲音箱

Sechoer 23



用户手册

产品说明



1 电源键

2 三合一按钮:音量;旋转调节音量, 按压对讲

3 频道键

4 喇叭网

5 Type-C充电硅胶塞

6 喇叭硅胶膜

7 卡扣配置绑带

操作说明

按键/操作	操作	功能
音乐/电话操作		
长按一秒	开机/关机	
轻点一次	播放/暂停	
轻点一次	挂断电话	
长按一秒	接听电话	
+	音量键	音量加
-	音量键	音量减
蓝牙配对		
长按 Sechoer23 配对		
电源键 双击 (音乐暂停时)		断开连接
对讲模式		
双击		打开/关闭
对讲键	长按	对讲发射
PTT	长按	对讲接收

所有设备设置相同频道即可开始对讲

产品参数

型号	Sechoer23
蓝牙版本	5.4
距离	40m
频率	60Hz-20KHz
信噪比	70dB
对讲距离	1.5km
输入电压/电流	DC5V±0.7A
工作时间	>40h (70% 音量)
充电时间	3h
电池容量	1500mAh
重量	140g

服务事项

如有任何问题, 欢迎联系我们: service@sechoer.com

制造商

深圳市尚爱普科技有限公司

中国广东省深圳市宝安区福海街道康乐社区2号

深圳市宝安区5A1栋3楼

邮编: 518000