

115mm

75mm


inland™

USER MANUAL

Specification information

Connection methods	Bluetooth 5.1/5.2
Number of keys	4 keys
DPI	800-1200-1600, (default 1200)
Product dimensions	113.02*57.82*26.64mm
Charging cable specification	50 cm Type-C cable
Return rate	250Hz
Battery specification	500 mAh lithium battery
Rated voltage/current	3.7V/15mA
Key life	3 million times
Charging time	Approximately 3 hours

Product Introduction



System requirements :

- *USBPort
- *Microsoft Windows 7/8/8.1/10
- *Chrome OS10.10.x or above

DPI: 800–1200–1600, default : 1200

Power ON key: switch to 2.4G for power on mode, switch to OFF for power off mode

Mode switch: The default mouse indicator green is 2.4GHz wireless mode. Tap once to switch to Bluetooth 5.1 mode, and the blue light flashes to automatically enter the search mode. Tap twice to switch to tooth 5.2 mode, and the red light flashes blue to automatically enter the search mode. Press and hold the mode switch key for 3 seconds, and the Bluetooth will reset into the matching mode.

Mouse use and setup:

- 1.Take out the wireless mouse and USB receiver from the packaging box and insert the receiver into the USB port of the computer.
- 2.Turn on the power switch, switch the mode switch key to any mode, and you can start using the mouse. (Bluetooth mode only supports Windows8, Chrome OS10.10.x or later versions)

Common problems:

- 1.If the mouse does not work properly, check whether it is powered on
- 2.Check whether the USB receiver is properly connected, or replace the USB port
- 3.If the device cannot be charged, check whether the USB terminal and TYPE–C terminal are in poor contact

4.If the battery is insufficient, please charge the mouse in time. When the mouse enters low voltage, the alarm light at the mouse wheel flashes 3 times every 5 seconds. When the mouse enters low voltage, the mouse will automatically shut down and stop working

Automatic sleep and precautions:

- 1.If you do not use it for more than 30 seconds for a long time, it will automatically enter light sleep mode, and if it exceeds 6 minutes, it will automatically enter deep sleep mode, which is an environmentally friendly and energy –saving design.
- 2.When used again, you only need to press any key to wake up quickly.
3. If it is not used for a long time, it is recommended that you switch the power switch to the OFF gear and shut it down completely, which can extend the battery power consumption and battery life.



FCC Statement

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.