



Quick Start Guide

快速使用说明书

クイックスタートガイド


Guía de inicio rápido

Kurzanleitung

빠른 사용 설명서

Guide de démarrage rapide

Guida rapida



EN

- ① Earbud Indicator Light
- ② Touch Control Area
- ③ Microphone
- ④ Charging Pins
- ⑤ Charging Case Indicator Light
- ⑥ Type-C Charging Port

日本語


- ① イヤホンインジケータランプ
- ② タッチ操作エリア
- ③ マイク
- ④ 充電ピン
- ⑤ 充電ケースインジケータランプ
- ⑥ Type-C 充電ポート

中文

- ① 耳机指示灯
- ② 触控区
- ③ 麦克风
- ④ 充电PIN口
- ⑤ 充电仓指示灯
- ⑥ Type-C 充电口

Español

- ① Luz indicadora de auricular
- ② Área de control táctil
- ③ Micrófono
- ④ Pines de carga
- ⑤ Luz indicadora del estuche de carga
- ⑥ Puerto de carga Type-C



Deutsch

- ① Anzeigeleuchte der Ohrhörer
- ② Touch-Bedienfeld
- ③ Mikrofon
- ④ Ladkontakte
- ⑤ Anzeigeleuchte des Ladeetuis
- ⑥ Type-C-Ladeanschluss

Français

- ① Voyant lumineux des écouteurs
- ② Zone de commande tactile
- ③ Microphone
- ④ Broches de charge
- ⑤ Voyant lumineux du boîtier de charge
- ⑥ Port de charge Type-C

한국어

- ① 이어버드 표시등
- ② 터치 컨트롤 영역
- ③ 마이크
- ④ 충전 핀
- ⑤ 충전 케이스 표시등
- ⑥ Type-C 충전 포트

Italiano

- ① Spia luminosa degli auricolari
- ② Area di controllo touch
- ③ Microfono
- ④ Pin di ricarica
- ⑤ Spia luminosa della custodia di ricarica
- ⑥ Porta di ricarica Type-C

How to Wear




Figure 1

1. Pinch the earbud head with your thumb and index finger to take out the earbud.




Figure 2

2. Insert the rear end of the earbud into the space between the upper ear cartilage and the head.





Figure 3

3. Rotate the earbud backward along the gap until it reaches a comfortable position.

Touch Controls



Call Controls

Single tap



Answer call

Answer call

Double taps



Reject call / End call

Reject call / End call

Music Controls

Single tap



Play / Pause

Play / Pause

Triple taps



Previous track (left)

Next track (right)

Recording Controls

Press and hold for 2 seconds

Start / Stop recording

Start / Stop recording

Factory Reset※

Tap 8 times



(Either earbud)



Factory Reset


Factory Reset

※ This only clears the Bluetooth pairing information between the earbuds and all devices. The device SN binding with the app must be unbound within the app.

Bluetooth Connection

01 Connect via Phone Bluetooth Settings

- Open the charging case. Confirm that one earbud flashes white light, and the other flashes a white light once every 5s.
- Go to the phone's Bluetooth settings, select **"Capmind One"**, and confirm the status shows **Connected**.




02 Download the Capmind App

- Search for **"Capmind"** in the Apple App Store and download it.
- Register your Capmind account.




03 Add Device in the App

- On the App home page, tap **"Add Device"** at the top to search for devices via BLE.
- Tap **"Bind"** until the full SN code is displayed. Tap **"Done"** to complete device binding.



Recording

Prerequisite: Please make sure the earbuds are connected to the app before recording.



Start Recording

Press and hold **either earbud for 2 seconds**, or tap **"Start Recording"** in the app. When you hear the voice prompt **"Recording"** from one earbud, recording has started.

End Recording

During recording, press and hold **either earbud for 2 seconds**, or tap **"End"** in the app again. When you hear the voice prompt **"Recording Ends"**, recording has stopped.


Notice:

- During recording, **only the primary earbud records** (the primary earbud is assigned randomly). You can identify the primary earbud by:
 - a. The earbud that plays the **"Recording"** voice prompt when recording starts;
 - b. The earbud with a **red breathing indicator light** during recording;
 - c. When phone Bluetooth is turned off or not connected, the earbud with a **rapidly flashing white light**.
- For **traditional phone calls**, recording stops automatically when the call ends. For **VoIP / internet calls**, recording must be stopped manually (via the app or by pressing and holding the earbud for 2 seconds).

Recording Modes


Call Recording

When making a **phone call** or a **media call (online meetings)**, pressing and holding the earbud for **2 seconds** will start **Call Recording**. The earbuds capture two party's voice during the call.




Live Recording · Earbuds

When the earbuds are **not in a call and not playing media**, pressing and holding the earbud for **2 seconds** will start **Live Recording · Earbuds**. The earbud mics capture **all surrounding voices**. The best voice pickup range is within 1.5 meters.



Media Recording*


When the phone is **playing media** (such as YouTube, podcasts, or live streams), pressing and holding the earbud for **2 seconds** will start **Media Recording**. Only the **device's media playback audio** is recorded; **external sounds are not captured**.



* Note:

“Media Recording” may sometimes be misidentified as “Live Recording · Earbuds”. For best results, it is recommended to return to the app and **manually select “Media Recording”** each time.

**Thank you for choosing Capmind! Scan to
get more detailed instructions.**



中文

感谢选择 Capmind! 扫描以获取更详细的操作说明。

한국어

Capmind를 선택해 주셔서 감사합니다! 스캔하여 더 자세한 사용 설명을 확인하세요.

Français

Merci d' avoir choisi Capmind. Scannez pour obtenir des instructions plus détaillées.

Italiano

Grazie per aver scelto Capmind. Scansiona per ottenere istruzioni più dettagliate.

Español

Gracias por elegir Capmind. Escanee para obtener instrucciones más detalladas.

Deutsch

Vielen Dank, dass Sie sich für Capmind entschieden haben. Scannen Sie, um ausführlichere Anweisungen zu erhalten.

日本語

Capmind をお選びいただきありがとうございます。まず、スキャンして、より詳しい操作方法をご確認ください。

✉ support@capmind.ai

☎ +1 747 306 1338

📱 Capmind App or Capmind.ai

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.