

H12



- ① **♥**: Long press to turn on/off; short press to switch playback mode (BT/FM/TF); double-click to switch lighting effects.
- ② **▶**: Short press to play/pause; Short press to answer a call long press to reject; short press to hang up in a call, double-click to call back; Double click TWS function: After both machines are turned on, first do not connect to Bluetooth. Long press either machine to pair the other machine successfully, and then connect either machine to the Bluetooth of the phone. This allows both machines to use the same phone's audio source and play the same music simultaneously; Long press in FM mode to automatically search for channels.
- ③ **◀**: Long press to switch to the previous song, Short press to reduce playback volume.
- ④ **▶**: Long press to switch to the next song, Short press to increase the playback volume.



Type-C charging port

⑤ **TF**: TF card interface

PACKING LIST

1. Speaker: 1pc
2. User Manual: 1pc
3. USB Charging Cable: 1pc

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.