

RADIATED PHOTOS



**9KHz to 30MHz
(EUT was placed in the centre of the turntable)**



30MHz to 1GHz

(EUT was placed in the centre of the turntable)



1GHz to 18GHz

(EUT was placed in the centre of the turntable)



18GHz to 25GHz

(EUT was placed in the centre of the turntable)