


Smart Home Aroma Diffuser

USER GUIDE

YN-813B

Dongguan Innovation Lighting Co., Ltd.
Room 101, Building 5, No.11, Hongfu Road, Huangjiang
Town, Dongguan City, Guangdong Province.



*Please read the instructions carefully before using the product and keep the user manual in a safe place for future reference.

READ AND SAVE THESE INSTRUCTIONS

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING.


IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRICAL APPLIANCE, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

- Use this product only for its intended use as described in this manual.
- Always place diffuser on a firm, flat, level surface.
- Always keep diffuser vertical When the oil bottle is installed to reduce the likelihood of oil leakage and damaging the diffuser.
- DO NOT use non-recommended attachments.
- DO NOT place or store this product where it can fall or be dropped into a tub or sink.
- DO NOT place or drop into water or any other liquid.
- Turn off product when not in use.
- NEVER operate this product if it has a damaged cord, plug, cable, or housing.
- DO NOT use any other AC adapter and power cord than what is supplied with the product. Use of any other AC adapter or power cord may damage the product and may increase the risk of harm to the user or property. Only the AC adapter with part No part PP-ARMHADPWT (white) should be used.
- DO NOT attempt to modify or repair the unit. Servicing must be performed by professional or qualified personnel.
- Always keep away from heated surfaces, high temperatures, and fire.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.
- NEVER cover the product when it is in operation.
- Children must use this product only with adult supervision.
- Keep this product out of the reach of children.
- DO NOT use outdoors.
- This product is intended for indoor, household use only.
- DO NOT expose diffuser to fire or excessive temperatures. Exposure to fire or temperatures above 125°F may cause an explosion.
- Follow all charging instructions and do not charge the diffuser outside the temperature range specified in the instructions. Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire. Product operating and charging range: 0°C – 40°C.

WARNING: This product has an internal, non-replaceable lithium-ion battery. This battery is not user-serviceable. Please dispose in accordance with local, state, province, and country regulations.


HOW TO USE



1. Remove diffuser top
2. Twist off empty bottle (keep for occasional maintenance or oil change out)
3. Twist on fragrance oil bottle to the diffuser top
4. Place diffuser top and attached oil bottle back into the diffuser base
5. Use the adapter and cable provided to charge the diffuser and enjoy your cordless diffuser once fully charged
6. Download our Putee app for a fully customizable experience

Control Panel (on diffuser base)

Battery charging indicator



Power button:

1. First short press to turn on unit
2. Short press to navigate through intensity settings: low, med, high
3. Long press to turn off unit and LED lights

Light button:

1. First short press - Turns ON ambient light
2. Short press - cycle through colors and light breathing mode. First press will change light color and second press will put that color into breathing mode
3. Long press - Turns OFF ambient light

Timer button:

1. Short press will cycle through preferred timer setting
2. Timer off = continuous operation

HOW TO OPERATE

Power ON

Plug in adapter and power cable to wall and diffuser. If plugged in already, press button located on the diffuser base or on the Bluetooth app.

Power OFF

Long press power button to turn OFF diffuser and LED lights.

Bluetooth® set up

App Installation

1. For iOS devices, please download the "Putee" App from App Store.
2. For Android devices, please download the "Putee" App from Google Play.

Bluetooth Pairing & Connection

1. Launch the Putee App and log in as instructed.
2. On the App homepage, tap Pair and then Search Devices.
3. Select the device named K813A (with MAC address suffix) from the device list.
4. Complete pairing following in-app guidance. Enter the control interface once connected successfully.

Intensity Setting

The diffuser has 3 scent intensity levels: low, medium and high. On the diffuser base, press  to increase or decrease the intensity. You can also customize the scent intensity on the Bluetooth app.

Your diffuser is set to mist and pause at different time intervals based on the intensity setting you choose.

Ambient light

Press  to choose your preferred light settings. You can also customize the light settings on the Bluetooth app.

Timer

Press  on diffuser to cycle through the timer options: 1, 2, 4, or 8 hours and off. You can also customize the desired timer setting on the Bluetooth app.

BATTERY CHARGING INDICATOR

Low battery indicator

When battery level is approximately 20%, the battery charging indicator on the back of the diffuser will illuminate red. When the battery is at 10% or lower, the battery charging indicator and the ambient light will both flash red. The diffuser will automatically shut off when the battery is depleted, and the battery indicator will flash red 5 times if you try to turn the diffuser ON.

During charging

When plugged in, the battery charging indicator will illuminate white and blink while charging. A full charge takes approximately 6.5 hours.

Fully charged

When fully charged, the battery charging indicator will turn OFF. Runtime: approx. 14 hours per full charge.

COMMON QUESTIONS

- Why does the mist start and then stop?
- What do the different strength settings mean?

Portable Waterless Home Fragrance diffuser is designed to mist and pause at different time intervals based on the intensity you select. Based on the intensity setting you choose, your diffuser will release visible aroma mist for a few seconds and then pause, before starting to mist again.


EQUIPMENT CLEANING

The diffuser may need to be cleaned when:

1. You're about to change to another 120 ml oil bottle.
2. The mist volume becomes weak.

Cleaning steps:

1. Use a cotton swab dipped in 90% isopropyl alcohol to clean the base of the mist tube located in the bottom of the diffuser head.
2. Add some isopropyl alcohol (minimum 90%) to the empty 120ml bottle (provided with your diffuser).
3. Install this bottle to the diffuser and turn the diffuser on high. Let it work for 30 minutes.
4. Turn off diffuser, remove bottle with isopropyl alcohol, and replace with bottle of fragrance oil.



TROUBLESHOOTING


Before asking to have the machine repaired, please try to diagnose the problem following the below instructions.

Breakdown	Solution
Not diffusing	• Make sure the power is ON. • The diffuser mists intermittently, so check to see if misting resumes after a few minutes. • The pump is damaged and needs replacing. • If there is no diffusion or it is weak, follow the cleaning instructions above.
Weak mist output	• Atomization head is blocked. Follow the cleaning instructions above. • Diffuser core with mist tube is missing or damaged.
Diffuser spitting liquid	• Machine is tilted or angled. Make sure it's upright at all times.
Oil leaking	• Bottle is loose. Screw it in properly and straight. • Seal is broken or missing.
Will not turn on	• The battery may be depleted. • Use the provided power cable to plug in and charge the battery.

REPLACEMENT PARTS



EMPTY BOTTLE
FOR CLEANING
PP-HEO120BOTTLE



POWER CABLE
WHITE CHARGING CABLE (1.6M)



MIST TUBE
PP-ARMTBFL1

REPLAPRODUCT SPECIFICATIONS

ITEM	CONTENT
Dimensions	Φ114.5×292.5 mm
Net Weight	830 g (±25 g)
Gross Weight	1225 g (±25 g)
Single Package Dimensions	156x134x318 mm
Rated Input Voltage	DC 5V/1A
Rated Power	5 W
Essential Oil Bottle	120mL
Noise Range	≤32 dB at 1 meter distance
Bluetooth Name	K813A (suffix + MAC address)
Bluetooth/Timer/ Level Indicator Light	White
Certifications	FCC、CE、ROHS、REACH

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.