

SELFISTICK

使用说明

一体追踪云台

云台操作说明

- 长按开机键3秒开机/关机。开机即跟随，单击暂停/开始跟随。
- 将摄像头调整照到面部，检测到人脸绿灯常亮，即进入跟随模式。
- 手势功能：手掌手势1秒停止跟随，OK手势1秒恢复跟随。
- 单人模式：耶手势指示灯闪烁后，只跟优先进摄像头的人，其他人经过只闪灯不跟随，当云台暂停跟踪后，OK手势或者单击开关机按键进入多人模式，跟随最识别的人，可通过前后站立位置进行切换。
- 识别不到人脸，20秒后自动关机，低电量时红灯闪烁，一分钟后自动关机。

遥控器操作说明

连接蓝牙:
拨动开关机键开机，LED灯闪烁蓝灯即已开机。然后打开手机的蓝牙选项，搜索设备蓝牙名为selfie-8，点击完成配对，显示已连接即完成。

蓝牙耳机使用Type-c充电接口，可充电续航(充满电后约操作5000次左右)

开机/关机 拍照 Type-c充电口

遥控器操作说明

- 开机:**向上拨动开关机按钮开机，指示灯闪烁进入搜索状态。
- 蓝牙连接:**打开手机蓝牙搜索selfie-8，点击连接，连接成功后指示灯熄灭。
- 拍照:**遥控器与手机处于连接状态时单击拍照键，指示灯闪烁并拍照。
- 开机后连接好蓝牙，无操作5分钟，设备进入的低功耗休眠状态，任意点击操作都可唤醒。无操作10分钟后断开蓝牙连接，自动关机。
- 关机:**向下拨动开关机键，指示灯闪烁熄灭并关机。
- 重新开机后，蓝牙自动回连正常使用。
- 充电时红灯常亮，充满后熄灭，充电电流100mA

关于安卓系统手机个别出现按遥控器为加音量/调焦距/或无反应的问题的解决方案
1.打开手机进入拍照界面。2.向左滑动或者找到相机设置。3.点击音量键功能。4.将音量键功能设置为快门(不要选缩放或者对焦)。5.个别手机相机设置路径不同,请自行查找

取出自拍器

向上滑动取出蓝牙遥控拍照

可充电电池

快速充电。直接充电无需更换电池。
手机充电宝可充电。

夹子可旋转

自由翻转，横竖拍实现多角度拍照，拍照更随心

怎么打开四脚架

在手柄底部找到“PUSH”按键，按下按钮，四脚架自动向外弹出，顺着方向调整到合适角度即可

稳固云台上手就拍

拍摄不用小心翼翼，画面很稳很清晰，手柄可360°旋转

360°旋转稳固云台

平滑顺畅。轻轻松松拍出全景大片

四脚架模式

捏住电键件向下推动或向上提起，以打开或关闭脚架。

产品参数

颜色: 黑
夹手机尺寸: 6.5-10cm

遥控器参数

适用系统: 兼容苹果/安卓/鸿蒙
蓝牙名称: selfie-8
遥控距离: 10米(30英寸)
电池: 聚合物电池(150mAh)
充电电流: 100MA
充电接口: Type-C
发射频率: 2.402GHZ-2.480GHZ
适配器充电电压/电流 5V/1-3A

SELFISTICK

INSTRUCTIONS

Integrated tracking gimbal

Pan tilt operation instructions

- Press and hold the power button for 3 seconds to turn on/off the device. Follow immediately upon startup, click pause/start following.
- Adjust the camera to focus on the face and detect that the green light on the face is constantly on, then enter the following mode.
- Gesture function: Palm gesture stops following for 1 second, OK gesture resumes following for 1 second.
- Single player mode: After the Ye gesture indicator light flashes, only the person with the advanced camera will follow. Other people passing by will only flash the light and not follow. When the gimbal pauses tracking, use the OK gesture or click the power button to enter the multiplayer mode. Follow the most recognizable person and switch between forward and backward standing positions.
- Unable to recognize face, automatically shuts down after 20 minutes, red light flashes when low battery, automatically shuts down after one minute.

Remote Controloperation

Remote Control:
Toggle the power button to turn on or off the device. When the LED light flashes blue, it indicates that the device has been powered on. Then, enable the Bluetooth option on your mobile phone, search for the device with the Bluetooth name 'selfie-8', click to complete the pairing, and when 'Connected' is displayed, the process is complete.

This product uses a Type-c charging interface and has a charging range (approximately 5000 operations after fully charging)

Power on/off photo Type-c charging port

Remote Controloperation

- Power on: Slide the power button upward to turn on the device. The indicator light flashes as it enters search mode.
- Bluetooth connection: Open the phone Bluetooth search for 'selfie-8' and click on the connection. After successful connection, the indicator light will turn off.
- Take a photo: When the remote control is connected to the phone, click the take photo button, and the indicator light will flash and take a photo.
- After turning on the device, connect Bluetooth and wait for 5 minutes without any operation. The device enters a low-power sleep state and can be awakened by any click. After 10 minutes of inactivity, disconnect the Bluetooth connection and automatically shut down.
- Shutdown: Slide the power button down, and the indicator light will flash and then turn off, powering the device down.
- After restarting, Bluetooth will automatically reconnect and function normally.
- The red light is always on during charging, but goes out when fully charged, with a charging current of 100MA

A Solution to the Problem of Individually Pressing the Remote Control to Increase Volume/Adjust Focus/ or Not Responding on Android System Mobile Phones
1: Open the camera to enter the photography interface. 2: Swipe left or find the camera settings. 3: Click on the volume button function. 4: Set the volume key function to shutter (do not select zoom or focus). 5: Individual mobile camera settings have different paths, please search for them yourself

Remove The Self Timer

Slide up to take out the Bluetooth remote control for taking photos

Rechargeable battery

ndroid micro interface. No need for direct charging eplace the battery. The mobile phone charging easure can be charged.

Clip can rotation

Flip freely and shoot horizontally and vertically to take photos from multiple angles, which is more.

How do I open the tripod

Find the "PUSH" button at the bottom of the handle and press it, the four legs will automatically pop out, and adjust them to the appropriate angle along the direction.

Stable platform

There is no need to be careful in shooting. The picture is very stable and clear.

360° PTZ panorama

Smooth and smooth. Take a panoramic picture with ease.

Tripod mode

Pinch the electroplated part and push it down or lift it up to open or close the tripod.

Product Parameters

Color: black
Clip phone size: 6.5-10cm

Remote Controi Parameters

Applicable system: compatible with Apple /Android/Hongmeng
Bluetooth name: selfie-8
Remote control distance: 10 meters (30 inches)
Battery: Polymer battery (150mAh)
Charging current: 100MA
Charging interface: Type-C
Transmission frequency: 2.402GHZ-2.480GHZ
Adapter charging voltage/current 5V/1-3A

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.