

说明书展开尺寸：200*140mm，对折后尺寸:100*140mm，单色双面印刷，80G书写纸

FM

Press M button and switch to FM mode, then press▶|◀ to scan channels automatically. Short press◀◀ and ▶▶ button to switch channels.

AUX-IN

Connect the audio cable to the AUX IN jack, press MODE to switch to AUX IN mode. In the AUX IN mode, track switching cannot be controlled from the speaker, but can be controlled from the connected device.

CHARGING

Plug the USB cable into the speaker’s charging port and connect it to a power source.

The red LED indicator will light up while charging.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CLEAR
SERIES

SPEAKER MANUAL
MODEL NO.: GLOW-2



FEATURES

Wireless connectivity
Supports USB / TF Card / FM Radio
Rechargeable Lithium battery
AUX IN function

ACCESSORIES


USB Charging Cable ×1
User Manual ×1

SPECIFICATIONS

Driver unit size	: 3"
Impedance	: 2.50hm
S/N ratio	: ≥80dB
Separation	: ≥45dB
Distortion	: ≤1.0%
Frequency response	: 100Hz-20KHz
Wireless version	: V5.3
Wireless range	: 10 meters
Wireless pairing name	: CLEAR GLOW-2
Wireless profiles supported	: A2DP
USB & TF the max supported memories	: 32 GB
Battery capacity	: Built-in 1500mAh
Battery type	: Li-ion
Playback time	: 1.5H at 75% volume
Charging indicator	: Yes
Input power	: DC 5V

HOW TO CONNECT THE UNIT

Turn on the speaker and enable Wireless mode on your mobile device. Search for “CLEAR GLOW-2” and pair the device. Once paired, the speaker will automatically reconnect to the last paired device when powered on again.



- 1.Power ON/OFF
- 2.AUX IN
- 3.USB slot
- 4.MIC slot
- 5.TF slot
- 6.C Type charging port
- 7.Previous track/Volume-
- 8.Next track/Volume+
- 9.Bass
- 10.LED light shift
- 11.MODE button
- 12.Play/Pause

WIRELESS

Turn on the speaker and it will enter Wireless mode automatically. After pairing, music can be played from the connected device. Press “▶|◀” the “Play/Pause” button to play or pause music. Short press “◀◀/-” or “▶▶/+” button to be previous track or next track. Long press is Volume-/Volume+.

USB/TF CARD

Insert a USB drive or TF card into the slot. MP3 music files will play automatically. Press▶|◀ to Play/Pause, short time press◀◀ and ▶▶ to Prev. and Next.