

Instruction Manual

Product Name:BT keyboard

Model:x10

NOTE:

1.Before use, verify the package contents are complete and undamaged!

All parts have to be unpacked and the packaging material has to be removed completely.

Pairing instructions:

1.Before the keyboard can be used, it should be connected with your tablet, PC or other device.

2.The connection, called pairing, should be performed only once. After that the keyboard will keep re-connecting automatically.

3.Turn the keyboard on with the "OFF/ON" switch.

4.In the Bluetooth menu of your device (for tablets found among Settings) you will **find the Bluetooth keyboard. Then just tap Connect to get connected.**

Troubleshooting

If the keyboard does not work properly, check the following:

1. Make sure the Bluetooth function on your device is enabled.
2. Make sure the keyboard is within 10 meters of your device.
3. Make sure the keyboard battery is charged.
4. If everything seems correct, try restarting your device and the keyboard.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.