


OVERVIEW



Megaphone User Manual

Setting Up

Cell Battery



Cell Battery
Insert 6 × "C" cell batteries to the clear sleeve as + - mark, the load the whole sleeve to megaphone

Lithium Battery



make sure indicator light is upward

Megaphone Technical Parameters

Function: Speak/Siren/Record/USB/AUX/TF/Bluetooth
Powered By: 6×C Batteries(Not Included)
Rechargeable Battery: 7.4V Lithium, 1500mAh
Max Power: 50 Watt MAX
Transmission Distance: 500 meters
Product Size: 7.48*7.48*13.97inch
Product Weight(without batteries): about 840g
Max Record Second: 240s
Working Voltage: 9V

Power/MIC Function

- ①. After the battery is correctly placed, the button needs to be transferred to the ON position, and when the power indicator is red, it means that it has been powered on.
- ②. Press the SPEAK button on the portable mic to start talking. In order to effectively capture your voice, it is recommended to place your mouth within about 2inch(5cm) of the portable mic.

Record Function

- ①. First, make sure the megaphone is powered properly.
- ②. Press the RECORD button. After the recording indicator lights up, you can directly hold the portable Mic to start talking(do not press the SPEAK button). The maximum recording time is 240s.
- ③. Press the RECORD button again to end the recording. And then press the PLAY button to play.

Siren Function

- ①. Make sure power is on, siren function works as soon as SIREN button pressed. Default maximum volume.

MP3 Player Function

1. Playing music or audio.

- ①. Switch mode by pressing the B/M button.
- ②. SD CARD & USB: Insert a memory card into the SD card slot ,or insert a flash drive into the USB port. The audio will automatically begin playing.
- ③. AUX INPUT: If using a mobile device, connect it to the AUX input with a mini-plug connector. Play and control the audio from the device.
- ④. BLUETOOTH: When the indicator light flashes, you can turn on the Bluetooth function of the phone to connect to the "Megaphone Bluetooth", and then you can use it normally.

2.MP3 Player Operation

▶ play/pause	Play/Pause: Pause and resumes playing the MPS
◀◀ / V-	Short Press: Skip to previous track Long Press: Decrease volume
▶▶ / V+	Short Press: Skip to next track Long Press: Increase volume
M (Recall MARK)	M: Short Press: Selects between SD Card/USB/AUX input and Bluetooth function

Warnings

1. Please reduce the volume to a minimum when testing and do not directly at the human ear to avoid hearing damage.
2. Please remove the batteries when the megaphone is not in use for a long time.
3. Please replace batteries when sound volume is not loud enough.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.