

尺寸：60*130mm，折页，彩印。

Smart glasses Please read the instruction manual before using this product.	Replace the lenses Steps to remove the lens: Press the lower left/right corner of the lens with your thumb to detach it (As shown below, press the area marked with the blue fingerprint.) Steps for installing eyeglass lenses: 1. Insert the inner side of the lens into the groove of the eyeglass frame. 2. Then press the outer side of the lens to secure it in place.	EN 1.Appearance Description 2.Operating Instructions	3.App Installation and Connection 4.Product Features 5.Precautions	中文 1.外观说明 2.操作说明	3.安装连接APP 4.产品功能 5.注意事项	FCC Caution:	
---	---	---	---	---	--	-------------------------	-------------