

Pearl Clip 真无线蓝牙耳机
使用说明书

包装清单



耳机x2



充电仓x1




USB-C 充电线x1




说明书x1

产品简介



充电仓指示灯



Type-C 充电口



耳机敲击按键



耳机充电金属触点

给耳机充电

- 1.当耳机的电量过低时,耳机会播报低电提醒,每5分钟提醒一次直至耳机低电关机,此时请及时给耳机充电。
- 2.在充电仓电量充足的情况下,将双耳机放回充电仓,充电仓的灯亮1秒耳机进入充电状态,约 2.5小时后充满。

给充电仓充电

使用配套的USB-C充电线给本机进行充电,约2小时完成充电。



DC5V

USB 充电线

充电仓

充电仓

充电仓电量及指示灯说明

用USB-C线给充电仓充电	把耳机放回充电仓	
橙灯	0-20%	橙灯亮1秒 电量<20%
白灯	20-90%	白灯亮1秒 电量>20%
白灯长亮	100%	

产品操作说明

①开机

打开充电仓上盖,耳机自动开机

②关机

将耳机放回充电仓,充电仓LED灯亮1秒盖上充电仓上盖耳机自动关机

注:开机后,在未连接手机或未被使用超过30分钟的情况下,耳机会自动关机

③配对

步骤一:开机后,左右耳自动互连后进入与手机配对状态(提示音:"dong dong")

步骤二:打开智能设备的蓝牙列表,搜索"Pearl Clips"并连接(提示音:"dong dong")



连接设备成功,语音提示:
"dong dong"



敲击操作

■ 音乐模式

播放/暂停:双击任一耳机敲击按键,

或者双耳放回充电仓时音乐暂停

上一曲:三击左耳机敲击按键

下一曲:三击右耳机敲击按键

■ 通话模式

接听来电:双击任一耳机敲击按键,

结束通话:双击任一耳机敲击按键

拒接电话:三击任一耳机敲击按键

重置为原厂设定

- 1.将左右耳机放入充电仓,充电仓的灯亮1秒,双耳机进入充电状态。
- 2.同时长按充个电仓按键约 8 秒直至充电仓红绿灯交替闪烁5次。
- 3.此时取出双耳机至提示音停止播放,即代表重置完成。


产品规格

蓝牙版本: V5.3
工作距离: 12m
耳机电池: 45mAh
充电仓电池: 300mAh
喇叭直径: 10.8mm
耳机充电时间: 约2小时
充电仓充电时间: 约2小时
输入电源: 5V 150mA(Max)
音频解码: AAC, SBC, AptX

(所有的技术信息以实际性能为准)

产品安全须知

- 1.产品内含电池,请勿将本产品暴露在强日照或暖炉等过热环境中。请勿将本产品储存在高温,强光及强磁场环境下。
- 2.产品不可放置于火源附近等恶劣环境中,禁止敲击、投掷、践踏、挤压或投入火中,若出现膨胀,请勿使用。
- 3.请勿违反产品说明书不恰当使用,造成产品损坏或危及人身财产安全,后果自行承担。
- 4.非专业人员严禁分解本产品,否则可能会导致起火,甚至彻底损坏本产品。请勿将本产品置于水中(或洗衣机中),若由于个人原因导致耳机损坏,责任需自行承担,本公司将不进行售后退换货服务。




True Wireless Earphones
使用说明书

包装清单



耳机x2



充电仓x1




USB-C 充电线x1




说明书x1

产品简介



充电仓指示灯



Type-C 充电口



耳机敲击按键



耳机充电金属触点

给耳机充电

- 1.当耳机的电量过低时,耳机会播报低电提醒,每5分钟提醒一次直至耳机低电关机,此时请及时给耳机充电。
- 2.在充电仓电量充足的情况下,将双耳机放回充电仓,充电仓的灯亮1秒耳机进入充电状态,约 2.5小时后充满。

Charge the Charging Case

使用配套的USB-C充电线给本机进行充电,约2小时完成充电。



DC5V

USB 充电线

充电仓

充电仓

Charging Case Battery Level & LED Indicator Status

用USB-C线给充电仓充电	把耳机放回充电仓	
橙灯	0-20%	橙灯亮1秒 电量<20%
白灯	20-90%	白灯亮1秒 电量>20%
白灯长亮	100%	

Close the charging case before charging.

产品操作说明

①开机

打开充电仓上盖,耳机自动开机

②关机

将耳机放回充电仓,充电仓LED灯亮1秒盖上充电仓上盖耳机自动关机

注:开机后,在未连接手机或未被使用超过30分钟的情况下,耳机会自动关机

③配对

步骤一:开机后,左右耳自动互连后进入与手机配对状态(提示音:"dong dong")

步骤二:打开智能设备的蓝牙列表,搜索"Pearl Clips"并连接(提示音:"dong dong")



连接设备成功,语音提示:
"dong dong"



敲击操作

■ 音乐模式

播放/暂停:双击任一耳机敲击按键,

或者双耳放回充电仓时音乐暂停

上一曲:三击左耳机敲击按键

下一曲:三击右耳机敲击按键

■ 通话模式

接听来电:双击任一耳机敲击按键,

结束通话:双击任一耳机敲击按键

拒接电话:三击任一耳机敲击按键

重置为原厂设定

1. Place both the left and right earbuds into the charging case. The charging case LED will light up for 1 second, and both earbuds will enter charging mode.
2. Press and hold the button on the charging case for about 8 seconds until the charging case alternately flashes red and green 5 times.
3. Then remove both earbuds from the charging case until the prompt tone stops playing. This indicates that the reset is complete.

产品规格

Bluetooth version: V5.3
Working distance: 12m
Earbud battery: 45mAh
Charging case battery: 300mAh
Speaker driver diameter: 10.8mm
Earbud charging time: approx. 2 hours
Charging case charging time: approx. 2 hours
Input power: 5V 150mA (Max)
Audio codecs: AAC, SBC, AptX

(All technical information is subject to actual performance)

产品安全须知

- 1.This product contains battery. Do not expose it to strong sunlight or overheated environments such as near a stove. Do not store it in environments with high temperatures, strong light, or strong magnetic fields.
- 2.Do not place the product near fire sources or in harsh environments. Do not strike, throw, step on, crush, or throw it into a fire. If swelling occurs, do not use it.
- 3.Do not use the product inappropriately against the instructions. Any damage caused or risk posed to personal or property safety will be at your own risk.
- 4.Non-professionals are strictly prohibited from disassembling this product, as it may lead to fire or complete damage to the product.
- 5.Do not place this product in water (or in a washing machine). If damage occurs due to personal reasons, the responsibility will be at your own risk, and the company will not provide after-sales return or replacement services.

FCC Warning 15.19 Labeling requirements. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. 15.21 Information to user. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 15.105 Information to the user. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver.	-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. FCC RF Exposure Warning Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions. FCC ID: 2BWKM-PEARLCLIP
--	---