

LIMITLESS™

Ultra Slim 5,000mAh  
Magnetic Wireless Power Bank

Quick Start Guide



WHAT'S INCLUDED

- (1) Ultra Slim 5,000mAh Magnetic Wireless Power Bank
- (1) 36" USB to Type-C Charging Cable
- (1) Magnetic Ring
- (1) Microfiber Carrying Pouch



COMPONENTS

1. Digital Display
2. Rotating Kickstand
3. Type-C Port
4. Type-C Built-In Cable
5. Type-C to Lightning® Adapter
6. Wireless Charger
7. Power Button
8. Magnetic Ring



CHARGING & RECHARGING

**Recharging the Power Bank:** Plug the included 36" Type-C to USB Charging Cable into the Type-C Port. Plug the opposite end of the Charging Cable into a USB power source (not included). The Digital Battery Level Indicator will blink while charging until it reaches 100%. **NOTE:** Only the second digit blinks while charging the Power Bank.

**Checking the Battery Level:** Press the Power Button to show the current battery capacity on the Digital Display or, you can check the Battery Level by connecting a device.

**Charging a Device via Built-In Type-C Cable:** Pull out the Built-In Cable and connect the Type-C connector to your device. The device will begin to charge.  
**Note:** You may need to remove your phone case to charge your mobile device.


**Charging a Device via Type-C to Lightning® Adapter:** Locate the Type-C Built-In Cable. Plug the Type-C end directly into the Lightning® opening (**directly next to the Type-C Cable in the cable slot**).

Attach the Lightning® Adapter to the Type-C connector, then plug it into your device.

Once the Adapter is installed, plug it into the charging port of the device. The device will begin to charge.

**Charging a Device via Type-C Port:** Plug a compatible Type-C cable into the port, and plug the opposite end into a device. The device will begin to charge.

**Charging via Wireless Charger:** Flip the power bank so the back (marked with a lightning bolt symbol) faces your phone. If your phone or phone case is MagSafe®-compatible (iPhone 12 or newer), the Power Bank will automatically align and magnetically attach for a secure connection.



If your phone or phone case is not MagSafe®-compatible, please refer to the "**USING THE MAGNETIC RING**" page section in this User Manual to utilize the Magnetic Wireless Charging feature.

Align your device with the wireless logo on the back of the Power Bank. If it's compatible with MagSafe®, the Power Bank will secure to the device via magnetic connection. The device will begin to charge.

**No MagSafe®?** The Power Bank is compatible with phones that are enabled with wireless charging. Align your device with the wireless logo on the back of the Power Bank. The device will begin to charge.

**NOTE:** If the device does not begin to charge, adjust the positioning of the Wireless Charger until there is a successful connection.

**⚡ Fast-Charging Icon:** You'll see a green lightning bolt icon when a device capable of fast-charging is connected to the Power Bank using the Type-C Port, Built-In Cable or the Wireless Charger. Keep in mind that some devices might not display this green icon, but they will still receive the fastest charging speed the Power Bank can deliver and the device can accept.



USING THE MAGNETIC RING

**NOTE:** The Magnetic Ring is to be used with non-MagSafe® phone cases, and with phones that are compatible with Wireless Charging, but not MagSafe® compatible.


If a case is not MagSafe® compatible, the phone will not have a strong connection with the Power Bank. It's recommended to remove the case or use the Magnetic ring.

**Placing the Ring:** Place the Magnetic Ring on the Magnetic Wireless Charger by aligning to the impression on the Power Bank. The adhesive liner should be facing outward.

Place the Power Bank over the back of the phone and adjust until the phone begins to wirelessly charge. **NOTE:** Do not remove the liner from the Ring in this step.

Once you have a good feel for where the Power Bank needs to be located to wirelessly charge your phone, remove the unit and peel off the liner from the Ring.

Place the Power Bank back over the phone, but keep slightly above and move back into position. Once you hear the phone start charging wirelessly, press down so the Ring can adhere to the back of the phone or phone case.



USING THE KICKSTAND

To use the Built-In Kickstand, gently pull it outward from the back of the Power Bank until it opens.

Once opened, the Kickstand can rotate 360°, allowing you to adjust your phone to the ideal viewing angle in portrait or landscape mode.

When finished, rotate the Kickstand back into place and press it flat against the Power Bank until it is fully closed.

**NOTE:** Do **NOT** force the Kickstand beyond its natural movement range.



TECH SPECS

**Model:** LIM-5KMSPB-XXXX

**Battery Capacity:** 5,000mAh | 19.25Wh

**Recharging Time (From 0%):**  
**Using included USB-A to Type-C Cable with Type-C Port:** 2 Hours

**Type-C Input:** 5V≡3A | 9V≡2A | 12V≡1.5A | PD 18W

**Type-C Output:** 5V≡3A | 9V≡2.22A | 12V≡1.67A | PD 20W

**Type-C Built-In Cable Output:** 5V≡3A | 9V≡2.22A | 12V≡1.67A | PD 20W

**Wireless Charging Output:** 15W | 7.5W | 5W

**Type-C to Lightning® Adapter Output:** 5V≡2.4A | 12W

**Temperature Range (Operation):** 32°-113°F (0°-45°C)

**Dimensions:** 4.29" x 2.83" x 0.43"

**Weight:** 0.24 lbs

WAIVER & RELEASE

By using the Limitless Ultra Slim 5,000mAh Magnetic Wireless Power Bank, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless Ultra Slim 5,000mAh Magnetic Wireless Power Bank. By using the Limitless Ultra Slim 5,000mAh Magnetic Wireless Power Bank, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless Ultra Slim 5,000mAh Magnetic Wireless Power Bank, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless Ultra Slim 5,000mAh Magnetic Wireless Power Bank.

WARNINGS

- The Ultra Slim 5,000mAh Magnetic Wireless Power Bank is **NOT** a toy and should be kept away from children.
- Do **NOT** use the Ultra Slim 5,000mAh Magnetic Wireless Power Bank near a magnetic or electric field.
- Keep the Ultra Slim 5,000mAh Magnetic Wireless Power Bank in a cool and dry place away from heat sources, moisture, and dust. Avoid leaving the device in places with high temperatures such as cars parked under the sun.
- Do **NOT** use the Ultra Slim 5,000mAh Magnetic Wireless Power Bank if it has been damaged and/or modified.
- Do **NOT** submerge the Ultra Slim 5,000mAh Magnetic Wireless Power Bank or its accessories in water.
- Do **NOT** insert any foreign objects into the USB or Type-C output port or joining terminals of the Ultra Slim 5,000mAh Magnetic Wireless Power Bank. Short circuits may present risks of excessive heat, fire or explosion.
- Be cautious of drops, bumps, abrasions, or other impacts to the Ultra Slim 5,000mAh Magnetic Wireless Power Bank. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Limitless Innovations or dispose of it in accordance to state and local guidelines.
- Do **NOT** attempt to disassemble, repair, or open the Ultra Slim 5,000mAh Magnetic Wireless Power Bank or its accessories in any way.  
**CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate.
- Do **NOT** use at an altitude higher than 6,562 feet (2,000 meters).

- If the Ultra Slim 5,000mAh Magnetic Wireless Power Bank is not used for long periods of time, you should charge and discharge once every three months.
- When charging a device, the Ultra Slim 5,000mAh Magnetic Wireless Power Bank may feel warm, this is a normal operating condition and should not be cause for concern.
- All products have gone through a thorough quality assurance inspection. If you find that your Ultra Slim 5,000mAh Magnetic Wireless Power Bank is excessively hot, is emitting odor, is deformed, abraded, cut, or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Limitless Innovations.
- Batteries should be recycled or disposed of, as per state and local guidelines. Do not throw in the trash, as this can create a fire hazard.
- Do **NOT** apply excessive force on the Ultra Slim 5,000mAh Magnetic Wireless Power Bank or drop it: By doing so, it may damage the internal components of the device, and risk short circuiting the device when used.
- Do **NOT** overcharge the Ultra Slim 5,000mAh Magnetic Wireless Power Bank as this may cause it to overheat and deplete efficiency. If the device becomes excessively hot during charging or discharging, unplug it from the power source or device immediately.
- Do **NOT** subject the Ultra Slim 5,000mAh Magnetic Wireless Power Bank to harsh chemicals.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

AIR TRAVEL

- This Power Bank is Approved to Carry-On Most Airplanes. Check Your Airline for Latest Guidelines.
- **DO NOT** travel with the Power Bank in your checked baggage. Labels on our shipping box refer to bulk shipping ONLY.
- For more information, visit:  
<https://www.faa.gov/hazmat/packsafe#hazardousMaterial>

Scan to learn more about using the features of your Ultra Slim 5,000mAh Magnetic Wireless Power Bank



LIMITLESS™

Designed in USA. Made in China.  
All rights reserved. Limitless™ is a trademark of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. All other trademarks included herein are property of their respective owners. Accessories sold separately.

LimitlessInnovations.com

Support@LimitlessInnovations.com

(855) 843-4828

© Limitless Innovations, Inc.



@LimitlessInnovations



/LimitlessInnov



/LimitlessInnov



/LimitlessInnov



Limitless Innovations

**15.105 Information to the user.**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-

Consult the dealer or an experienced radio/TV technician for help.

**FCC RF Radiation Exposure Statement:**

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
3. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

The FCC ID label is located inside. Please open the latches on the back of the power bank to see it.