



A103



USER MANUAL

Product Introduction



- 1.power button
- 2.USB-C Input/output
- 3.Power Indicator Light
- 4.USB-C cable output
- 5.Wireless Charging Output

Preface

Dear users, thank you for purchasing our products. In order to further understand the product, please read this manual carefully before use. Wish you a happy experience!

Specification

Product Name	Power Bank with Detachable Lanyard Cable
Model	A103
Battery Capacity	5000mAh(19.2Wh)
Type-C Input	18W
Type-C Output	22.5W
Wireless Charging Output	7.5W/15W
Product Size	68.44*104.50*13.01mm/2.69*4.11*0.51 in
Product Weight	
Packing List	Power Bank*1,User Manual*1, USB Cable*1




How to Use Magnetic Wireless Power Bank?

1.Placement of Equipment

- Align the back of the phone for wireless charging to the power bank (as shown below). to ensure a tight fit between the two.
- Avoid misalignment, otherwise it may cause charging interruption or reduced efficiency.

2.Start to Charger

- After successful connection, the power bank and phone screen will display the charging status (such as the indicator light being constantly on and the phone popping up a charging prompt).
- If there is no response, try adjusting the phone position or restarting the power bank.






Attention

1. NOT Compatible with Non-Magnetic Phone Cases.




2. Magnetic Wireless charging only for the iPhone 12 ~16 Series or later.



Multiple Charging Mode with the Detachable Lanyard Cable & USB-C Port

1. Charge Through The Detachable Lanyard Cable:

Connect the cable that comes with the power bank into your phone.



2.Charge Through USB Output Ports:


Take out the charging USB cable that coming with your phone, connect the correct port to the power bank and your phone respectively.



How to Recharge the Power Bank

Recharge Through Type-C Input Port

- Please use the included charging cable to connect the pd port of the power bank and an AC adapter or a power supply device with a USB-C jack(such as a PC).



Notice

1. The AC adapter is not included in the package.
2. For faster charging, please recharge the power bank using an adapter with 18W or higher power output.
3. The included charging cable is used to charge your devices or recharge the power bank.
4. When charging or discharging, some heat may be generated due to energy loss during transmission. This is normal.
5. Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
6. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
7. leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

8. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
9. When disposing of secondary cells or batteries, keep cells or batteries of different electrochemical systems separate from each other.
10. Operating temperature should be between 32°F to 104°F / 0°C to 40°C.
11. Recommended storage temperature: 15°C–25°C (59°F–77°F), humidity 45%–75% RH.
12. For long-term storage, maintain a state of charge (SOC) of 40%–60%.
13. Do not expose to temperatures above 60°C or below -20°C for extended periods.
14. If the battery is hot or abnormal, please discontinue use immediately.
15. If the product is not being used a long time, it should be charged and discharged every three months.

After-sale Service

If you have any questions about the product, please contact us via this email: **support02603@163.com**. We will be glad to assist you.

FCC Statement

1.This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Note: This equipment has been tested and found to comply with the limits for a class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a particular installation.if this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.