

TRUE WIRELESS EARBUDS



Model No: AG01

PRODUCT FEATURES

- Bluetooth version : 6.0
- Voica assistant compatible: siri
- Touch contorl: music play/pause, next/last track ,
- volume +/--accept/end/reject callsvoice assistant
- Charging interface : Type-C
- Pocket Friendly/Light Weight Case

TECHNICAL SPECIFICATIONS

Bluetooth version	6.0
Support	A2DP,AVRCP,HSP,HFP
Bluetooth frequency	20HZ-20KHZ
Bluetooth range	10m
Earbuds battery	25mAH
Charging case battery	200mAH
Charging time	1.5-2h

PACKAGE CONTENTS

The product contains the following contents.
If any of the following items are missing,
please contact us immediately.

S/N	Items	Qty
1	True Wireless Earbuds Unit	1
2	Type-C Charging Cable	1
3	User Manual	1
4	L Size Eartip	2
5	S Size Eartip	2

BEFORE FIRST USE

In order to have a very good
experience,pls charge the
charging case and earbuds
before you use them.



CHARGING LED

When you charge the case,the case LED flashes red light.
When the case is fully charged,The red light is constantly on.

Power ON: 1. Open the charging case, and take out of the
earbuds from the case.
2. Long press 2s on both L and R earbuds.

Power OFF: 1. Put both earbuds into the charging case.
2. Long press 6s on L or R earbud.

CONNECTING EARBUDS TO YOUR PHONE

1. As soon as open the charging case,
and take the earbuds out of the case,
both Left&Right earbuds pair automatically.
2. You can search" MINISO-AG01" in your mobile phone & click it
to connect.

Note: Earbuds will be OFF if not connected with any devices in 3 minutes.



Going to Previous Song

3 times touching MFB on Left earbud

Going to Next Song

3 times touching MFB on Right earbud

Pause /Play song

A Single touch on MFB on either of
the earbud to Pause /Play the song

Receiving Call /End Call

A single touch on MFB on either of
the earbud to receive /end a call

Using Voice Assistance /Siri

Press either of the Earbud on MFB for 2 seconds
and the Voice Assistance /Siri will be activated

Note:Control functions may vary as per the device connected.

Volume Up /Down

2 times touching MFB on Right
earbud to increase

2 times touching MFB on Left
earbud to decrease the volume

Refuse Call

Press either of the earbud on
MFB for 2 seconds to refuse the call

SAFETY INSTRUCTIONS

1. Earbuds should be stored in a dry and ventilated
environment to avoid contact with oil, steam, moisture, dust,
etc., to avoid affecting product performance.
2. Avoid using irritating organic solvents or items containing
these ingredients to clean earbuds.
3. Earbuds should be used correctly and in a standardized
manner as required, and attention to the impact of the use
environment as well. To ensure smooth connection, the
distance between the phone and earbuds should be within
10 meters.
4. If earbuds has other problems such as poor connection or
communication, please do not disassemble the earbuds body
and accessories without permission, otherwise the warranty
will not be granted.
5. Please choose a standard car charger or a qualified charger
designated by our company to charge the earbuds.
6. To ensure your normal use of earbuds, please ensure that
the earbuds has sufficient power.

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
- (2)this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses,
and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does
cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,
the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation