


LEVI STAR



FLOATING SPEAKER



USER MANUAL




This product contains magnets. Please do not approach anything that is easily affected by magnetism. Children should use it under the supervision of an adult.



How to install


- Check installation accessories

M3 screws *4 Support legs *2
Screwdriver *1 Base *1



- Place one support leg in the corresponding position on the Base, Using the accompanying tools, Install 2 M3 screws, Install 2 M3 screws on the other side using the same method.
The installation of the support legs is complete.

How to connect




Power on/off:

Press and hold the power button for 3 seconds to turn on the speaker orb power, and the annular LED light will light up to enter the pairing state to connect With other device. Pressing and holding the power button for 3 seconds to turn off the speaker orb power.

Connect Bluetooth audio:


After turn on the speaker, the annular LED lights up continuously, indicating that the current status is waiting for connecting. Devices with Bluetooth audio such as mobile phones or computers are searching to pair Bluetooth, and the name is DS AUDIO. A prompt tone will sound when the connecting is successful. At the same time, the annular LED light rotates to indicate. If you want to connect to another Bluetooth device, you must disconnect the existing connected device before it can be searched for and connected by the other device.

How to charge



- ① Plug the power adapter included in the accessories into the magnetic base. Please only use the adapter included in the accessory to supply power to this product. Do not use other adapters to avoid damaging this product.
- ② To charge the speaker orb, please use the TYPE-C cable included in the accessory, plug one end into the charging interface of the speaker orb and plug the other end into any power source that can output 5V (such as a mobile phone charger, computer USB interface, etc.)

How to levitation



Hold the speaker orb with both hands, align the top blue disc with the center of the levitating base, move the orb slowly from the below of the base upward to the center of the top base until feeling the orb is gripped firmly, when you master the levitating method, it is easy to successfully levitate.


There is a temperature protection function inside, when the temperature is too high due to multiple operations, it will be powered off for protection. Please wait for a moment before continuing the levitation operation.

Please connect the speaker orb with the intelligent device before levitating it to the base.


Matters need attention




Please place the base on a flat, non covered desktop to set it up.
Stable levitation requires stable placement, and tilting angles greater than 3 degrees will result in inability to levitate.



Metal objects that are too close to each other may interfere with normal levitation or cause personal injury. When the levitation is stable, do not place metal objects near the magnetic levitation space.



The design uses relatively sharp support legs, please pay attention to avoid injury.



Magnetic levitation is with strong magnet inside. Please keep objects susceptible to magnetic influence away from at least 30cm/1.18inch.

Specification

Name: Magnetic Levitation Speaker

Model: KC3

Bluetooth Name: DS AUDIO

Speaker: 2.24in/57mm loudspeaker

Battery: lithium ion 3.7v/1500mAh

Base Power: DC 12V 1000mA

Orb Charge: Type-C Port DC 5V 500mA

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user ' s authority to operate the equipment.

This device complies with part 15 of the FCC Rules. operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- _ Reorient or relocate the receiving antenna.
- _ Increase the separation between the equipment and receiver.
- _ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- _ Consult the dealer or an experienced radio/TV technician for help.