



INSTRUCTION MANUAL

PRODUCT DESCRIPTION




REMOTE CONTROL INSTRUCTIONS



1. BUILT-IN INTELLIGENT PROGRAMMING MODULE, ENABLING VARIOUS INTERESTING COMBINATIONS.
2. VOICE REMOTE CONTROL COMMANDS INCLUDE:


(1). SLIDE FORWARD	(2). SLIDE BACKWARDS
(3). WALK FORWARD	(4). WALK BACKWARDS
(5). TURN LEFT	(6). TURN RIGHT
(8). GET DOWN	(9). ATTENTION
(11). TELL A STORY	(12). ACT COQUETTISH
	(13). PUSH UP

REMOTE CONTROL DEMONSTRATION



REFERENCE FOR PROGRAMMING ACTIONS


BY INTELLIGENTLY COMBINING VARIOUS ACTIONS AND FUNCTIONS THROUGH PROGRAMMING, THE PRODUCT CAN OFFER MORE GAMEPLAY OPTIONS, GUIDING BABIES TO EXPLORE MORE FUN.



15 STAND + 8 PUSH-UP + 16 SIT DOWN + 5 ADVANCE

PRESS THE PROGRAMMING KEY ⑩, THEN PRESS ⑮ STAND + ⑧ PUSH-UP + ⑯ SIT DOWN + ⑤ ADVANCE IN SEQUENCE. FINALLY, PRESS THE PROGRAMMING KEY ONCE MORE. IF IT MAKES TWO BEEPS, IT INDICATES THAT THE PROGRAMMING IS COMPLETE.

VOICE FUNCTION REFERENCE




PRESS THE VOICE CONTROL KEY ⑭ (ASR) ON THE REMOTE CONTROL, THEN SPEAK YOUR COMMANDS CLEARLY. THE TOY WILL PERFORM THE CORRESPONDING ACTION. PRESS THE KEY AGAIN TO TURN OFF THE VOICE CONTROL FUNCTION.

VOICE REMOTE CONTROL COMMANDS INCLUDE:

- | | | |
|--------------------|------------------------|---------------|
| (1). SLIDE FORWARD | (2). SLIDING BACKWARDS | |
| (3). WALK FORWARD | (4). WALK BACKWARDS | |
| (5). TURN LEFT | (6). TURN RIGHT | (7). SIT DOWN |
| (8). GET DOWN | (9). ATTENTION | (10). DANCE |
| (11). TELL A STORY | (12). ACT COQUETTISH | (13). PUSH UP |

TOUCH SENSING


PRESS BUTTON ⑦ ON THE REMOTE CONTROL, GENTLY PAT THE BACK OF THE TOY, AND IT WILL MAKE FUN MOVEMENTS, ETC



REFERENCE FOR OPERATING MOBILE APP

SCAN THE QR CODE TO OPERATE THE TOY VIA THE MOBILE APP.

(NOTE: COMPATIBLE WITH IOS AND ANDROID, NOT COMPATIBLE WITH HUAWEI HARMONYOS)



SCAN THE CODE
TO LEARN THE
INSTRUCTIONS

1. SCAN THE QR CODE WITH WECHAT, DOWNLOAD THE APP, THEN LOG IN OR REGISTER.
2. ENABLE BLUETOOTH ON YOUR PHONE, THEN RETURN TO THE APP.
3. ENTER THE REMOTE CONTROL INTERFACE AND FOLLOW THE PROMPTS TO PAIR THE TOY.
4. ONCE PAIRED, YOU CAN CONTROL THE TOY VIA THE APP.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.