


Wireless Speaker User Manual



Operation

1. Long press  button for 3 seconds. The speaker will have a voice prompt and LED light will flash. Search for bluetooth pairing name BT SPEAKER on your mobile and click to pair. The speaker will have a voice prompt and connect successfully.
2. Press  button to play/pause the music in music mode; short press  button to answer the coming call and press twice  button to reject the call.
4. Press M button to switch the bluetooth mode and FM mode. In radio mode, short press  button to search the channels, it will store the channels automatically after searching. Then press - and + button to choose the last/next channels selection.

Button Function



1. short press: previous song; long press: volume down
2. mode switch
3. power on/off; play/pause (in music mode); answer/reject for coming call
4. short press: next song; long press: volume up
5. RGB light switch
6. USB flash drive slot
7. TF card slot
8. Type-c charging port

Charge the battery

1. Insert the charging cable into the Type-c port, the charging LED indicator is on.
2. After charging completed, the LED indicator will turn off.

Note: When music sound becomes smaller and you hear the warning tone, please charge the speaker in time.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.