

Golf Swing Analyzer

MT5206

USER MANUAL

Issued June 22, 2026 Printed in Japan
2026 Plesout Inc. All rights reserved.



Thank you for purchasing the Golf Swing Analyzer.
Please read this manual before use to ensure proper operation.
- Unauthorized reproduction of this manual, in whole or in part, is prohibited.
- The contents of this manual are subject to change without notice.

INQUIRIES AND SERVICE SUPPORT

For inquiries and service support, please visit the website below.

Support / Service Contact
<https://m-tracer.golf/contact/>



SELLER INFORMATION
Seller: Piles Out Inc.
HEP NAVIO 6F, 7-10 Kakudacho, Kita-ku, Osaka 530-0017, Japan

Manufacturer: Seiko Epson Corporation
Head Office: 3-3-5 Owa, Suwa-shi, Nagano 392-8502, Japan

WARRANTY

WARRANTY TERMS
1. If the product fails under normal use in accordance with this manual and the labels on the product, it will be repaired free of charge in accordance with this warranty.
2. To request free repair during the warranty period, present or include the product and this warranty. Shipping charges are the customer's responsibility.
3. Repairs will be charged even within the warranty period in the following cases:
1) This warranty is not presented.
2) Required information is missing or altered, or the dealer name is not shown.
3) Damage caused by disaster, earthquake, flood, lightning, other natural events, pollution, or abnormal voltage.
4) Damage caused by improper handling, transport, relocation, or dropping after purchase.
5) Damage caused by use contrary to the instructions or cautions in this manual.
6) Damage attributable to modification or misuse.
7) Replacement of consumable items.
8) Product labels or plates have been damaged or removed so that the product name or serial number cannot be identified.
4. We are not liable for direct or indirect damages arising from product failure or use.
5. Warranty coverage applies to the main unit only. Attachments and the battery are excluded.
6. For repair requests after relocation or when the product was received as a gift, consult the dealer or retailer shown on this warranty.
7. This warranty is valid only in Japan.
8. This warranty will not be reissued. Keep it in a safe place.

MODEL	
SERIAL NO.	
WARRANTY	1 year from date of purchase (main unit)
	Year Month Day
DEALER	
	Support: https://m-tracer.golf/contact/ https://m-tracer.golf/contact/

01 CHECK PACKAGE CONTENTS

Check that all items listed below are included. If anything is missing or defective, contact the retailer where you purchased the product.

- Main unit
- Attachments x3
- Top case opener
- Coin battery (CR2032)
- User manual / warranty

The battery is installed in the main unit at purchase and is insulated by an insulating sheet.
Remove the insulating sheet before use.

02 FOR SAFE USE

To use this product safely, be sure to read this manual before use. Failure to follow these instructions may cause malfunction or accident.
- Keep this manual available for reference whenever you have questions about the product.
- This product is intended for use only in Japan. If you take it outside Japan, check the laws and regulations of the country/region where it will be used.
This manual uses the following warning symbols to help prevent injury to users and others and damage to property. Read and understand their meanings before use.


	Ignoring this indication and handling the product incorrectly may result in death or serious injury.
	Ignoring this indication and handling the product incorrectly may result in injury or property damage.
	- Turn the power off in public facilities and vehicles. This product communicates wirelessly with a smartphone, and radio waves may affect nearby equipment and cause malfunction, accidents, or injury. - If the battery leaks, do not touch the liquid with bare hands. If it contacts your body, rinse immediately with tap water and seek medical attention; it may cause burns, injury, or loss of eyesight. - Do not leave the product near fire or heaters, in direct sunlight, or inside a hot vehicle. This may cause fire, burns, or battery deterioration. - Do not disassemble or repair the product yourself. Doing so may cause electric shock or accidents. - Keep the product out of reach of small children. Licking or placing it in the mouth is extremely dangerous. - Keep the coin battery out of reach of infants and small children. If swallowed, contact a physician immediately. Swallowing a coin battery can cause severe chemical burns and internal tissue damage in a short time and may be fatal.
	- The tip of the attachment is sharp. Take care to avoid injury. - Install and align the attachment correctly; incorrect installation may prevent accurate measurement. - Repeated installation/removal may wear the grip and enlarge the hole. Frequent removal is not recommended. - Some grips may not accept the attachment. - Before use, make sure the main unit and attachment are firmly secured to the golf club. If not secure, the unit may come off during a swing and be lost. - We recommend using a new golf-club grip. Hardened rubber may prevent secure attachment. - Do not touch the main unit during swing measurement. Contact by the hand or body may reduce measurement accuracy. - Remove the product from the golf club before storing or carrying the club. Leaving it attached may damage the product. - When placing it in a bag, do not place heavy objects on top. Damage to the case or battery may cause injury or burns. - Exercise according to your physical condition. Sudden or excessive exercise can be dangerous. - When swinging a golf club, ensure adequate clearance from people and objects. - Do not use the product for purposes other than those intended. - Do not throw the product or subject it to strong impact. This may cause damage, malfunction, or injury. - Do not immerse in water or allow foreign objects inside. The product is not waterproof and may malfunction or cause electric shock. - Do not leave in hot, humid environments or under direct sun; this may cause battery heating or swelling. - If the unit detaches at a driving range and flies toward the range or another bay, do not retrieve it carelessly. - When replacing the battery, use rubber gloves or similar protection and work carefully to avoid injuring your fingernails. - Battery consumption may increase in low-temperature environments, shortening battery life.

03 PARTS AND BASIC SPECIFICATIONS

ITEM
Communication
Bluetooth 5.0
Range
Approx. 4 m (no obstacles)*1
Operating time
Approx. 6 months*2*3
Battery
CR2032 lithium coin battery
Operating temp.
0 to +40 °C
Storage temp.
-20 to +45 °C
Water resistance
Main unit size
27 (dia.) x 15 (H) mm
Main unit weight
Approx. 10 g (incl. battery)
Attachment weight
Approx. 2 g

SPECIFICATION
Bluetooth 5.0
Approx. 4 m (no obstacles)*1
Approx. 6 months*2*3
CR2032 lithium coin battery
0 to +40 °C
-20 to +45 °C
Equivalent to IPX4*4
27 (dia.) x 15 (H) mm
Approx. 10 g (incl. battery)
Approx. 2 g


*1 Range varies depending on the environment and Bluetooth device performance.
*2 Operating time is based on our test conditions. *3 Assumes four sessions per month, 2 hours / 100 swings each.
*4 This specification does not guarantee waterproof performance.



04 BATTERY PRECAUTIONS

Install the coin battery with the TOP CASE side as (-) and the BOTTOM CASE side as (+).

- When replacing the battery, use a CR2032 lithium coin battery.
- Insert the battery with the correct polarity. Incorrect insertion may cause an external short circuit or rupture.
- The internal clock continues to operate even when the product is OFF and consumes battery power.
- Remove the battery if the product will not be used for a long period.



05 OPENING THE TOP CASE (BATTERY REPLACEMENT)

When replacing the battery, use the supplied top case opener. As shown at right, place the opener between the attachment and the top case and rotate it to remove the top case from the bottom case or to reinstall it.

Take care not to drop or lose the top case opener.

TO BACK

06 FCC REGULATORY INFORMATION

Product Identification

Product Name: Golf Swing Analyzer
Model: MT520G
FCC ID: 2BX39-MT520G

FCC PART 15 STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines as this equipment has very low levels of RF energy.

07 CLASS B / COMPLIANCE INFORMATION

Class B Digital Device Notice

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

U.S. Responsible Party Information

Company Name: Flightpath Golf LLC

Company Address: 20 N Orange Ave Suite 1100 Orlando FLORIDA 32801 USA

Contact us:: contact@flightpathgolf.com

Important

The FCC regulatory statements on this page are intended for the U.S. version of the MT520G user manual. Final statements should match the authorization method and test results confirmed for this model.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.