



THE PLUG

EN: Important Information Read First
SP: Información importante lee primero
FR: Informations importantes à lire en premier
DE: Belangrijke informatie Lees eerst
PT: Informações importantes, leia primeiro
IT: Informazioni importanti da leggere prima
AR: معلومات هامة اقرأ أولاً
CN: 重要信息 请务必先读
RU: Важная информация прочтите в первую очередь
JP: 重要な情報 最初にお読みください
KO: 중요한 정보를 먼저 읽어주세요

WWW.PARADISEPLEASUREPRODUCTS.COM

THE PLUG

QUICK START GUIDE

Welcome to Illumination by Paradise! You're holding a personal wellness device designed to bring a little extra joy, curiosity, and light into your self-care routine. Crafted from body-safe materials and shaped for easy, intuitive use, The Plug blends comfort, creativity, and versatility—for both first-time explorers and seasoned pros.

This manual will guide you through everything you need to know to get the most out of The Plug, from setup and operation to care and maintenance. Take a moment to read through the instructions so you can enjoy every feature confidently and safely. Get ready for a bright, playful step forward in personal wellness.

Before using the product for the first time, make sure that the local power supply matches the information provided in the technical data. Do not immerse the charger or charging cable in water or other liquids. Charging time may vary depending on the initial battery level. It is not necessary to fully deplete the battery before recharging. The product can be charged with a standard USB AC adapter that meets the required voltage and current ratings (adapter not included). To help maintain the battery charge it on a regular basis, even when not in use.

IPX7 Waterproof Device is protected from temporary submersion in water up to 1 meter (3.3 feet) deep for up to 30 minutes. When submerged, Bluetooth connectivity distance will be reduced.

CHARGING

When the light is flashing the device is charging

When the light is solid the device is fully charged



Connect the metal connector on the charging cable to the metal connector on the device.
*USB power adapter not included

CLEANING AND INSTRUCTIONS

Always clean the device before and after use. Wash the surface with warm water and a mild antibacterial soap or toy cleaner. Rinse well and dry completely with a soft, lint-free cloth. Ensure the product is completely dry before storing or charging. Check the product and charging components regularly for damage. Do not use if any part is cracked, frayed, or otherwise compromised. Do not expose the product or its battery to heat above 60°C (140°F). Do not open, crush, or modify the product or its internal components.

Use the product only as intended. Sharing personal products can transmit infections; if you share with a partner, use protective measures. Remove all piercings and jewelry from the area of use before operation. If the product behaves abnormally, turns on or off unexpectedly, or doesn't operate as described, switch it off and visit the support section on our website.

This model is designed for external and anal stimulation and includes a safety base to prevent over-insertion. Do not insert the device fully into the anus. If this occurs, discontinue use and seek immediate medical attention.

Insert and remove the device slowly and gently. Do not use desensitizing sprays or creams before insertion, as they may prevent normal pain responses. Do not use this product with silicone-based lubricants, as they may damage the surface. Always use a sufficient amount of water-based personal lubricant.

WWW.PARADISEPLEASUREPRODUCTS.COM

CONTROLS



POWER BUTTON



PATTERN BUTTON



INTENSITY BUTTON



LED BUTTON



POWER BUTTON: Press and hold for 2 seconds to power on/off the device. When powered on, press to cycle through the 3 stored profiles.



PATTERN BUTTON: Press to cycle through the 7 preset vibration patterns.



INTENSITY BUTTON: Press and release to cycle through the 5 levels of vibration intensity.

Press and hold to cycle the LED brightness. At max brightness, press and hold to lower brightness to lowest setting. Once released, the brightness will be locked.



LED BUTTON: Press to cycle through the 8 lighting profiles.

Once The Plug is charged, THE FUN BEGINS!!!



APP INSTRUCTIONS

- Go to your APP STORE on your phone and DL the Toys app
- Open the Toys app, you will be prompted to allow "Find Bluetooth Devices"
- Next you will be prompted to "Connect"
- Now you will be prompted to enter the product code **520198**
- You will now be connected to the device and see the Paradise logo and battery level indicator in the top right corner
- From the homepage you will have the following options:

Customize

In customize there are 3 tabs...

- Vibration Mode**
 - Select the strength through "Mode Strength"
 - Select 8 different vibration patterns through "Choose the mode you like"
- Lighting Effect Mode**
 - Select turn on/off, brightness, and the LED mode between 8 different color patterns.
 - Use "Select Color" to set a solid color
- Memory**
 - Once you select your Vibration mode/strength and Lighting mode/brightness, on your desired memory slot select save and use the top left arrow to return to the previous screen.
 - You can select any combination and can choose just lighting if desired
 - Memory slots will save to the device and can be selected without the app

To select the 3 different memory slots, press and release the power button to cycle through the 3 saved profiles.

APP INSTRUCTIONS cont

- Music Mode**
 - In music mode the vibration, pattern, and strength goes to the rhythm of music downloaded to your phone
- Sound Mode**
 - Sound Mode has its intensity and rhythm based on the environment/sounds around your phone. You can adjust the microphone sensitivity.
 - Press the microphone to turn on this mode.
- Immersion Mode**
 - Press and hold to control the vibration intensity, go up to lower the intensity, go down to raise the intensity.
- Shake Mode**
 - Shake the phone control the vibration on the toy
- Remote Mode**
 - In this mode you can play with your partner while not being in the same room, as long as both devices have an internet connection.
 - To join, both people select Remote mode
 - The person with the toy selects "Create Room"
 - Once in the room it will generate a room ID code at the top of the screen.
 - The other person press "Join Room" and then enter in the Room ID
 - In this mode you can also use the following options:
 - Customize
 - Immersion Mode
 - Music Mode
- Travel Mode**
 - Keep your device quiet and secure on the go.
 - Activate**
 - Hold the power button and the LED button together until it beeps 3 times to confirm it is in travel mode.
 - Deactivate**
 - Hold the power button and the LED button again until it beeps 3 times to confirm travel mode is off.

APP DOWNLOAD RESOURCES

SCAN THE APPROPRIATE QR CODE BELOW AND YOU WILL BE DIRECTED TO THE PROPER VERSION OF THE APP



PRODUCT CODE
520198

© 2023 Paradise Marketing Services, Inc.
All trademarks are the property of their respective owners.



WWW.BEARDINGSOFTWAREPRODUCTS.COM

de 100°C : supăratul este protejât de către frământător temporar care înăbușă mișcările de profundează pierdere 30 minute maximum. În caz eliminării, a 60 secunde, se ridică.

Age Group	Percentage
18-24	85%
25-34	75%
35-44	65%
45-54	55%
55-64	45%
65-74	35%
75-84	25%
85+	15%

PARADIGM PARTS PRODUCTS, CO.

[illegible]

PLEASE REPRODUCE

11. <http://www.who.int/mediacentre/factsheets/fs104/en/>

© 2018 Pensieve Marketing Services, Inc.
All trademarks are the property of their respective owners.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.