



THE RABBIT

EN: Important Information Read First
 SP: Información importante lee primero
 FR: Informations importantes à lire en premier
 DE: Bitte lesen Sie wichtige Informationen zuerst
 PT: Informações importantes, leia primeiro
 IT: Informazioni importanti da leggere prima
 AR: معلومات هامة اقرأ أولاً
 CN: 请先阅读重要信息
 RU: Сначала прочтите важную информацию
 JP: 重要な情報 最初に読んでください
 KR: 중요한 정보를 먼저 읽어보세요

WWW.PARADISEPLEASUREPRODUCTS.COM

THE RABBIT QUICK START GUIDE

Welcome to Illumination by Paradise! You're holding a personal wellness device designed to bring a little extra joy, curiosity, and light into your self-care routine. Crafted from body-safe materials and shaped for easy, intuitive use, The Rabbit blends comfort, creativity, and versatility—great for both first-time explorers and seasoned pros.

This manual will guide you through everything you need to know to get the most out of The Rabbit, from setup and operation to care and maintenance. Take a moment to read through the instructions so you can enjoy every feature confidently and safely. Get ready for a bright, playful step forward in personal wellness.

Before using the product for the first time, make sure that the local power supply matches the information provided in the technical data. Do not immerse the charger or charging cable in water or other liquids. Charging time may vary depending on the initial battery level. It is not necessary to fully deplete the battery before recharging. The product can be charged with a standard USB-A/C adapter that meets the required voltage and current ratings (adapter not included). To help maintain the battery, charge it on a regular basis, even when not in use.

IPX7 Waterproof: Device is protected from temporary submersion in water up to 1 meter (3.3 feet) deep for up to 30 minutes. When submerged, Bluetooth connectivity distance will be reduced.

CHARGING



When the light is flashing the device is charging



When the light is solid the device is fully charged



Connect the metal connectors on the charging cable to the metal connectors on the device. *USB power adapter not included.



Fully Assembled

WWW.PARADISEPLEASUREPRODUCTS.COM

CLEANING AND INSTRUCTIONS

Always clean the device before and after use. Wash the surface with warm water and a mild antibacterial soap or toy cleaner. Rinse well and dry completely with a soft, lint-free cloth. Ensure the product is completely dry before storing or charging. Check the product and charging components regularly for damage. Do not use if any part is cracked, frayed, or otherwise compromised. Do not expose the product or its battery to heat above 60°C (140°F). Do not open, crush, or modify the product or its internal components.

Use the product only as intended. Sharing personal products can transmit infections. If you share with a partner, use protective measures. Remove all piercings and jewelry from the area of use before operation. If the product behaves abnormally, turns on or off unexpectedly, or doesn't operate as described, switch it off and visit the support section on our website.

If using the product near or for anal stimulation, apply a generous amount of water-based personal lubricant and insert slowly. Insufficient lubrication may result in abrasion, laceration, or other injury. Never insert the product fully into the anal canal. If full insertion occurs, discontinue use and seek immediate medical assistance. To prevent cross-contamination, do not transfer the product from anal to vaginal use without protective methods and cleaning.

WWW.PARADISEPLEASUREPRODUCTS.COM

CONTROLS



POWER BUTTON



PATTERN BUTTON



INTENSITY BUTTON



LED BUTTON



POWER BUTTON: Press and hold for 2 seconds to power on/off the device. When powered on, press to cycle through the 3 saved profiles.



PATTERN BUTTON: Press to cycle through the 7 preset vibration patterns.



INTENSITY BUTTON: Press and release to cycle through the 5 levels of vibration intensity. Press and hold to cycle the LED brightness. At max brightness, press and hold to lower brightness to lowest setting. Once released, the brightness will be locked.



LED BUTTON: Press to cycle through the 8 lighting profiles.



Solo

Once The Rabbit is charged, THE FUN BEGINS!!!



Play with Friends

APP INSTRUCTIONS

- Go to your APP STORE on your phone and CL the (Play) app.
- Open the (Play) app, you will be prompted to allow "Find Bluetooth Device"
- Next you will be prompted to "Connect"
- Now you will be prompted to enter the product code **520197**
- You will now be connected to the device and see the Paradise logo and battery level indicator in the top right corner.
- From the home page you will have the following options:

Customize

(to customize these see 3 tabs...)

- Vibration Mode**
 - Select the strength through "Mode Strength"
 - Select 9 different vibration patterns through "Choose the mode you like"
 - Lighting Effect Mode**
 - Select turn on/off, brightness, and the LED mode between 9 different color patterns.
 - Use "Select Color" to set a solid color.
 - Memory**
 - Once you select your Vibration mode/strength and Lighting mode/brightness, on your desired memory slot select save and use the top left arrow to return to the previous screen.
 - You can select any combination and can choose just lighting if desired.
 - Memory slots will save to the device and can be selected without the app.
- To select the 3 different memory slots, press and release the power button to cycle through the 3 saved profiles.

APP INSTRUCTIONS cont.

- Music Mode**
 - In music mode the vibration, pattern, and strength goes to the rhythm of music downloaded to your phone.
- Sound Mode**
 - Sound Mode has its intensity and rhythm based on the environment/sounds around your phone. You can adjust the microphone sensitivity.
 - Press the microphone to turn on this mode.
- Immersion Mode**
 - Press and hold to control the vibration intensity, press to lower the intensity, go down to raise the intensity.
- Shake Mode**
 - Shake the phone control the vibration on the toy.
- Remote Mode**
 - In this mode you can play with your partner while not being in the same room, as long as both devices have an internet connection.
 - To play, both people select Remote mode.
 - The person with the toy selects "Create Room"
 - Once in the room it will generate a room ID code at the top of the screen.
 - The other person press "Join Room" and then enter in the room ID.
 - In this mode you can also use the following options:
 - Customize
 - Immersion Mode
 - Music Mode
- Travel Mode**
 - Keep your device quiet and secure on-the-go.
- Activate**
 - Hold the power button and the LED button together until it blinks 3 times to confirm it is in travel mode.
- Deactivate**
 - Hold the power button and the LED button again until it blinks 3 times to confirm travel mode is off.

APP DOWNLOAD RESOURCES

SCAN THE APPROPRIATE QR CODE BELOW AND YOU WILL BE DIRECTED TO THE PROPER VERSION OF THE APP



PRODUCT CODE
520197

© 2023 Paradise Marketing Services, Inc.
All trademarks are the property of their respective owners.



EN: Important Information Read first
SP: Información importante leer primero
DE: Bedeutende Informationen lesen zuerst
PT: Informações importantes, leia primeiro
IT: Informazioni importanti da leggere prima
AR: معلومات هامة اقرأها أولاً
CH: 請先閱讀重要訊息
RU: Важная информация, прочтите сначала
JP: 重要な情報 最初にお読みください
KR: 중요한 정보를 먼저 읽어주세요

EL CONEJO QUÉ DE MARCHÉ RAPIDE

Présenté à l'origine sous le nom de "The Rabbit", l'un des plus innovateurs de l'électrosexuel, ce produit a été conçu pour offrir un toucher doux de caresses, câlins et massage à l'intérieur d'une cavité intime. Fabriqué avec matériaux sûrs pour la santé et durable pour une utilisation à long terme, le Rabbit est un produit innovateur et durable.

Avant de commencer à utiliser le Rabbit, assurez-vous de bien lire la notice d'utilisation et les instructions de sécurité. Le Rabbit est un produit innovateur et durable. Avant de commencer à utiliser le Rabbit, assurez-vous de bien lire la notice d'utilisation et les instructions de sécurité. Le Rabbit est un produit innovateur et durable.

LE LAPIN QUÉ DE DÉMARRAGE RAPIDE

Le Rabbit est un produit innovateur et durable. Avant de commencer à utiliser le Rabbit, assurez-vous de bien lire la notice d'utilisation et les instructions de sécurité. Le Rabbit est un produit innovateur et durable.

Avant la première utilisation, assurez-vous de bien lire la notice d'utilisation et les instructions de sécurité. Le Rabbit est un produit innovateur et durable.

Resistant to water IPX 3. If the device is protected against immersion in water for up to 30 minutes. Do not use for more than 30 minutes.

Resistant to water IPX 3. If the device is protected against immersion in water for up to 30 minutes. Do not use for more than 30 minutes.

CARGAR

Quando lo far porpedere, el dispositivo se está cargando.

Quando lo far está fijo, el dispositivo está completamente cargado.

Connect the connectors metallic of the cable to the connectors metallic of the device.

Connect the connectors metallic of the cable to the connectors metallic of the device.

Connect the connectors metallic of the cable to the connectors metallic of the device.

Connect the connectors metallic of the cable to the connectors metallic of the device.

LIMPIEZA E INSTRUCCIONES

Use a soft cloth to clean the device. Do not use harsh chemicals or abrasive materials. The device is made of high-quality materials and is designed to be durable.

Use a soft cloth to clean the device. Do not use harsh chemicals or abrasive materials. The device is made of high-quality materials and is designed to be durable.

Use a soft cloth to clean the device. Do not use harsh chemicals or abrasive materials. The device is made of high-quality materials and is designed to be durable.

NETTOYAGE ET INSTRUCTIONS

Use a soft cloth to clean the device. Do not use harsh chemicals or abrasive materials. The device is made of high-quality materials and is designed to be durable.

Use a soft cloth to clean the device. Do not use harsh chemicals or abrasive materials. The device is made of high-quality materials and is designed to be durable.

Use a soft cloth to clean the device. Do not use harsh chemicals or abrasive materials. The device is made of high-quality materials and is designed to be durable.

COMMANDES

BOUTON DE MARCHÉ (ARRÊT): Appuyez et maintenez enfoncé pendant 2 secondes pour éteindre l'appareil. Une fois allumé, appuyez sur pour parcourir les profils enregistrés.

BOUTON À MOTIF: Appuyez pour faire défiler les 7 modes de vibration, pour parcourir les profils enregistrés.

BOUTON D'INTENSITÉ: Appuyez pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

BOUTON LED: Appuyez pour faire défiler les 7 modes de luminosité.

BOUTON À MOTIF: Appuyez pour faire défiler les 7 modes de vibration, pour parcourir les profils enregistrés.

BOUTON D'INTENSITÉ: Appuyez pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

BOUTON LED: Appuyez pour faire défiler les 7 modes de luminosité.

BOUTON À MOTIF: Appuyez pour faire défiler les 7 modes de vibration, pour parcourir les profils enregistrés.

INSTRUCTIONS DE L'APPLICATION

1. Appuyez sur le bouton de marche/arrêt pour allumer l'appareil. Une fois allumé, appuyez sur le bouton de vibration pour parcourir les profils enregistrés.

2. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

3. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

4. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

5. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

6. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

7. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

8. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

9. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

INSTRUCCIONES DE LA APLICACIÓN

1. Appuyez sur le bouton de marche/arrêt pour allumer l'appareil. Une fois allumé, appuyez sur le bouton de vibration pour parcourir les profils enregistrés.

2. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

3. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

4. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

5. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

6. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.



7. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

8. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

9. Appuyez sur le bouton de vibration pour modifier l'intensité des vibrations. Appuyez et maintenez enfoncé pour modifier la luminosité de la LED.

APP DOWNLOAD RESOURCES

SCAN THE APPROPRIATE QR CODE BELOW AND YOU WILL BE DIRECTED TO THE PROPER VERSION OF THE APP



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.