

Product Manual

Explain in detail

1. Press and hold the surface of  the product for more than 3 seconds until the indicator light turns on. Press again when it is on. Close after more than 3 seconds;
2. Each time you press it, it switches to a frequency, and when you press it for a long time,  it stops vibrating;
3. Apply lubricant before use; insert into body part and start using.

Attention and maintenance

1. Please clean and keep dry after use.
2. Store product in a cool, dry place away from strong sunlight/heat/pressure/humidity/pollute.
3. For personal use only, not a contraceptive product.
4. Please throw the battery into the recycling bin after use.

Fault description

1. The vibration becomes weak, please charge in time.
2. If the product does not work after being fully charged, please contact the seller for repair or replacement.

Warn

1. This product is only for use by adults over 18 years of age. Use by minors is prohibited.
2. If you feel any discomfort, please stop using it.
3. If the product is damaged, please stop using it.



FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.