

A3 双面 正128g铜版纸

PT 200c

*此页不印刷 此页不印刷 此页不印刷 此页不印刷 此页不印刷 此页不印刷 此页不印刷


USER MANUAL

* For better use of this product.
Please read this instruction manual carefully!

APP OPERATION INSTRUCTIONS

App-Download

Download the AI control app by scanning the QR code.



Connect and Play

Step 1

Turn on the toy and the phone Bluetooth.



Step 2

Tap Connect Toy in app to pair.



Features



Xfans



AI Novel



AI Image



Voice Clone



X-Game



Long-Distance



Video Sync



Voice Control



Remote

Scan for User Guides




01

OPERATION INSTRUCTIONS

Power / Function Button


- Press and hold "U" for 2 seconds to power on. The indicator light turns on with one vibration, and the device enters standby mode.
- Single-tap "U" to toggle among telescopic, tonguelicking and vibration functions in a 10-frequency cycle.
- Double-tap "U" to activate heating with the red light on; double-tap "U" again to deactivate heating and turn off the red light.
- Press and hold "U" for 2 seconds to power off. The indicator light turns off and all functions stop.




02

03

CLEANING INSTRUCTIONS



Can be cleaned underwater.
Please dry thoroughly after cleaning.




Do not immerse in water

CHARGING INSTRUCTIONS

- Before each charging, please clean and thoroughly dry the device.
- When charging, the indicator light will flash; after charging, the indicator light will stay on.
- Please use the charging cable provided.
- Please use a matching charger to charge, an unmatched charger may affect the battery life or damage the product.

Note: The product cannot be used while charging.



04

TROUBLESHOOTING STEPS FOR PRODUCT NOT WORKING

1. Incorrect Startup Procedure:

Press and hold the bottom button for 2 seconds to enter standby mode. When the indicator light flashes, it means the product is in standby mode only! Please do not assume the product is defective. Press the button briefly again to activate the function.
(This is the most common issue reported by users.)

2. Battery Depletion Due to Shipping:

If no light appears after long pressing the bottom button, please charge the product first.
When charging via the magnetic charger, the bottom button will flash to indicate it is charging. Once fully charged, the light will stay steadily on. After that, please follow the startup steps again.

3. Other Issues:

Please rest assured. You may contact us via Amazon (Page 7 of the user manual), and we will assist you as soon as possible.

TROUBLESHOOTING GUIDE FOR REMOTE CONTROL MALFUNCTION

- Check Battery Installation and Charge: Please ensure the battery is installed correctly with the proper polarity, and confirm that the provided battery has sufficient power.
- Check the Functionality of the Remote Control: Press any button on the remote. If the light turns on, the remote is functioning normally. If there is no response, please replace the battery.
- Incorrect Remote Usage Order: Please ensure the dildo is in standby mode or has the function activated before using the remote to press any button to switch functions.
- For Other Issues: If the problem persists, please don't worry. You may contact us via Amazon (refer to page 7 of the manual). We will provide assistance as soon as possible.

HEATING FUNCTION INSTRUCTIONS

Method 1 (Manual Operation):

- Press and hold the power button at the bottom for 2 seconds to enter standby mode (red light flashing).
- Press the power button twice quickly. When the red light turns a deeper shade of red, it indicates that the heating function has been activated.
- Press the power button again to activate both thrusting and vibration functions. Use the motor with the heating pad to preheat for about 5 minutes to achieve optimal heating performance.

05

Charging instructions:

- Before each charging, please clean and thoroughly dry the device.
 - When charging, the indicator light will flash; after charging, the indicator light will stay on.
 - Please use the charging cable provided.
 - Please use a matching charger to charge, an unmatched charger may affect the battery life or damage the product.
- Note: The product cannot be used while charging.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


NOTE 2:

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

06

ENCOUNTER ANY PROBLEM, PLEASE CONTACT THE SELLER THROUGH AMAZON.

METHOD 1



METHOD 2



Service Email: support@aavvip.com

07

BENUTZER- HANDBUCH

しようせつめいしよ

APP-BEDIENUNGSANLEITUNG/アプリ操作説明

App-Download

Laden Sie die KI-Steuerungs-App durch Scannen des QR-Codes herunter.

Verbinden und Spielen


Schritt 1

Spielzeug und Handy-Bluetooth einschalten



Schritt 2

In App Spielzeug verbinden antippen zum Koppeln



App ダウンロード

QRコードをスキャンしてAI制御アプリをダウンロードしてください。

接続とプレイ

ステップ1

おもちゃとスマホのBluetoothをオンにする。



ステップ2

アプリで“玩具接続”をタしてペアリング。




01

BEDIENUNGSANLEITUNG/操作説明

Ein-/Aus-Taste / Funktionstaste

- Halten Sie „“ 2 Sekunden lang gedrückt, um das Gerät einzuschalten. Die Anzeigeleuchte leuchtet auf, das Gerät vibriert einmal und wechselt in den Standby-Modus.
- Tippen Sie einmal auf „“, um zwischen Teleskop-, Zungenleck- und Vibrationsfunktion in einem Zyklus von 10 Frequenzen zu wechseln.
- Tippen Sie zweimal auf „“, um die Heizfunktion mit leuchtender roter Lampe zu aktivieren; tippen Sie erneut zweimal auf „“, um die Heizfunktion zu deaktivieren und die rote Lampe erlischt.
- Halten Sie „“ 2 Sekunden lang gedrückt, um das Gerät auszuschalten. Die Anzeigeleuchte erlischt und alle Funktionen stoppen.



電源ボタン / 機能切替ボタン

- 「」を 2 秒間長押しすると電源が入り、インジケータランプが点灯し、1 回振動して待機モードに入ります。
- 「」をワンタップすると、伸縮・舌舐め・振動機能を 10 段階のサイクルで切り替えられます。
- 「」をダブルタップすると赤ランプが点灯して加熱機能が起動し、再度ダブルタップすると赤ランプが消えて加熱機能が停止します。
- 「」を 2 秒間長押しすると電源が切れ、インジケータランプが消灯し、全機能が停止します。

02

03

LADEHINWEISE/充電方法

1. Vor jedem Laden das Gerät reinigen und vollständig trocknen.
2. Beim Laden blinkt die Anzeigeleuchte; nach vollständiger Ladung leuchtet sie konstant.
3. Nur das mitgelieferte Ladekabel verwenden.
4. Verwenden Sie einen passenden Ladestecker – inkompatible Ladegeräte können die Akkulaufzeit beeinträchtigen oder das Produkt beschädigen.

Hinweis: Das Produkt kann während des Ladens nicht verwendet werden.

1. 充電前に製品を清潔にし、完全に乾燥させてください。
2. 充電中はインジケータが点滅し、充電完了後は点灯します。
3. 付属の充電ケーブルのみを使用してください。
4. 対応する充電器を使用してください。非対応品はバッテリー寿命や製品破損の原因となります。

注: 充電中は使用不可です。



 ≤150 min  ≥50 min

Magnetisches Laden /
磁気充電

04

REINIGUNGSHINWEISE/クリーニング方法



05

WENN SIE EIN PROBLEM FESTSTELLEN, WENDEN SIE SICH BITTE ÜBER AMAZON AN DEN VERKÄUFER

METHODE 1



METHODE 2



Service-E-Mail: support@aavvip.com

06

問題がございましたら、AMAZONを通じて販売者にお問い合わせください。

方法1



方法2



サポートメール: support@aavvip.com

07