



CAGE GRIP KIT SMART REMOTE USER GUIDE

LAYOUT



PAIRING GUIDE

1. PUT THE REMOTE INTO PAIRING MODE



1S


1. Press the **S key** for 1 second to turn on the remote control; The Green Light will start blinking.

2. Press and hold both the **A key** and **S key** for 3 seconds to enter pairing mode; The blue light and green light will alternate blinking.



2. PUT THE CAMERA INTO PAIRING MODE

1. Turn on the camera.
2. Wait for the camera to display a connection request.
3. Click "Accept" on the camera to complete the connection.



FEATURES

On/off

Power On: Press the **S key** for 1 second.
Power Off: Press the **S key** for 3 seconds.

Mode

Press the **B key**, to switch the camera's modes You can select which modes are allowed to switch via the camera menu.



Shooting

Press the **S key** to start or end shooting.

Marking

Press the **B key** to mark a tag When Recording with supported camera model.

Put the camera into sleep mode or wake it up

Press and hold the **A key** for 3 seconds to put the camera into sleep mode.

While the remote control remains connected to the camera, press the **A key** to wake up the camera. You can enable or disable the Bluetooth wake-up function in the camera menu.

If the remote control is turned off, the connection will be lost and the camera cannot be remotely awakened. A previously paired remote control and camera will automatically reconnect when powered on.

Note: If the camera fails to wake up, try restoring camera to Factory Settings to resolve any issues.

Snapshot

When the camera is able to be awakened, pressing the **B key** will wake it up and trigger a snapshot. After that, the camera will automatically return to sleep mode.

Charing

When charging, the white indicator light will turn on. Once fully charged, the light will turn off. If the remote control is powered on while charging, the charging light will only stay on for 1 second before turning off.

CAGE GRIP KIT SMART REMOTE USER GUIDE

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.