

HOME TV AUDIO 5011V

User's manual

This product is sold without a power adapter. If you use a power adapter for power supply, you should purchase a supporting power adapter that has obtained CCC certification and meets the standard requirements.

Basic parameters


Effective distance:	≥10M
SNR:	≥75dB
Audio input:	3.5mm
Output power:	10W (THD+N=3%)
Frequency range:	60Hz-16KHz
Supply voltage:	BATT 3.7V

Product features

- 1、Support wireless connection, music playback and call function;
- 2、Support wireless connection back connection function;
- 3、Support TF card input;
- 4、Support USB flash disk input;
- 5、Support aux audio input;
- 6、Support coaxial input

Audio accessories

Your home TV speaker includes the following accessories:



1. One speaker host

2. One charging line



3. Common axis one



4. Manual, warranty card



Keys and functions:

1. ON / OFF

Power on: dial "ON"

Shutdown: dial to "OFF"

2. Wireless connection

a. After entering the wireless mode, search with your mobile phone or other devices, Conduct "5011V" pairing connection for the wireless device name. If you need to enter the pairing code as 0000, enter the wireless playback mode after successful pairing

b. After the device is paired successfully, the next time it enters the wireless mode, it will be automatically connected back to 10 S. After the connection back times out, it will enter the pairing state

3. Previous switch, next switch, pause / resume switch

Long press "◀" Key previous song switching

Long press "▶" Key next song switching

Short press "▶" The key is to switch between stop playing / continue playing

Short press "⏮" Mode switching (play USB file / play TF card file / play aux connection Device / Bluetooth mode switching)

4. Volume control

Short press "➤" Key volume increase key

Short press "◀" Key volume down key

Play USB flash disk / TF Card:

When the USB flash disk / TF card is inserted in the power on state, the sound will automatically switch to the USB flash disk / TF mode and give a prompt tone. Songs will be played automatically after 2 seconds. There must be MP3 and wav audio files in the USB flash disk / TF card

External audio aux input mode:

In the power on state, use the factory distribution line to insert the audio head of external devices (such as mobile phones, computers, MP3 and other audio input devices) into the "micro charging port". At this time, the audio will automatically switch to the external audio input mode to play the audio on the device.

Maintenance and repair

- When using, please read the following suggestions to help you comply with the warranty terms and prolong the service life of the product.
- Keep the product dry and do not put it in a wet place, so as not to affect the internal circuit of the product.
- Do not place the product in the sun or high temperature. High temperature will shorten the service life of electronic components and deform some plastic components
- Do not put the product in a supercooled place to avoid damaging the internal circuit board.
- Do not attempt to disassemble the product. If you are not a professional, you may damage the product.
- Do not drop, strongly vibrate or hit the product with hardware, so as not to damage the internal circuit.
- Do not scratch the product surface with a sharp body, so as not to damage the shell and affect the appearance.
- If the product does not work properly, please send it to your qualified maintenance organization, and the staff will be eager to help you solve the problem.

Product warranty card

Model / Name:	
User name:	
Place of purchase:	
Purchase date:	
Color:	
Warranty period:	

Explain:

1. If the warranty card can be used for maintenance. If the warranty card is lost, please keep it properly;
2. The company's product after-sales service regulations: the products sold are guaranteed for one year;
3. The maintenance of this product shall be sent to a professional warranty unit or a designated seller. The user shall not repair or dismantle it without authorization, otherwise he shall bear the consequences.

Certificate

Date: _____

Inspector: _____

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.