

可编程胎压传感器说明书

User manual

1.产品特点

TPS800-1 型可编程胎压传感器是配合 TPS800 胎压编程器使用的胎压传感器，该胎压传感器具有体积小，重量轻的特点。

TPS800-1 型可编程胎压传感器可以通过 TPS800 胎压编程器根据用户车型需求编程各种车型的胎压传感器软件，从而支持失眠上 95%车型使用。

2.产品参数

电压：3.0V

电流：静态 500nA

发送 8mA

防水等级：IP67

使用寿命：3 年

材质：PA66 + GF30

Programmable Tire Pressure Sensor Manual

1. Product Features

The TPS800-1 programmable tire pressure sensor is designed for use with the TPS800 tire pressure programmer, featuring a compact size and lightweight design.

The TPS800-1 programmable tire pressure sensor can be configured with software for various vehicle models via the TPS800 tire pressure programmer based on user requirements, supporting installation on 95% of vehicle models.

2. Product Parameters

Voltage: 3.0V

Current: Static 500nA

Send 8mA

Waterproof Rating: IP67

Service life: 3 years

material PA66 + GF30

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.