


PIXEL PRO

LED GLASSES

PIXEL PRO

LED GOGGLES



RF Wireless

GLOFX

PIXEL PRO

LED GLASSES

PIXEL PRO

LED GOGGLES

- When you first receive your Pixel Pro, the battery pack may need to be charged. Plug in with the included charger and let the battery charge for several hours.
- Getting started is easy! Just plug your glasses into the USB port of the battery pack, point your remote at the glasses, and press 
- To automatically scroll through modes, press 
- To manually scroll through all modes, press  
- See a mode you like? Add it to your favorites with . You can remove a favorite with 
- Scroll through your favorites by pressing  
- Control a moving mode's speed by pressing  . To adjust brightness, go to a solid color mode and press  
- To access solid color modes, press    
- Enjoy your Pixel Pro!

GLOFX

Need help? Contact us at:

Support@GloFX.com

844-GO-GLOFX (U.S.)

+1-850-559-6404 (International)

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.