


Digital Calendar

— ALL-in-One Family Calendar —

User Manual



Power Button

Hold the power button for about 5 seconds to power on the frame.

when the frame is on, press the power button once to turn the screen on or off.

Hold the power button for about 2 seconds to get power off option.

To avoid anypossible damage to the frame, please do not unplug the power adapter from the frame while the device is on.

Product Specification	
Screen	15.6" Touchscreen (16:10)
Resolution	1920x1080 FHD
WI-FI	2.4GHz+5GHz
CPU	A523Cortex™M-A55 Octa-Core
Memory	4GB
Storage	64GB

Before Device Installation

Wall-Mounting Tips

Take the height of all device users into consideration. It is recommended to install the device at an eye-level height.

Ensure sufficient space for both horizontal and vertical mounting orientations.

Do not drill holes above wall studs, electrical wires, or pipes.

Before installation, unplug the device from the power socket and keep it away from water sources.

Required tools



Electric Drill




Hammer



Wall Protection Tape

Other accessories inside the packaging box



Power Adapter



Bracket



Two Screws



Two Expansion Anchors

The included screws and expansion anchors are suitable for drywall, brick, concrete, or tile walls.

* For more operation instructions, please contact the store customer service.

Download AiMOR app on your mobile phone

To share your schedule with compatible calendar devices worldwide, please first download the free AiMOR app on your mobile device.

Search for "AiMOR" in the App Store (iOS) or Google Play (Android) to download the AiMOR app.



Bind and Connect Devices


To synchronize your schedule with AiMOR Calendar, you need to connect the AiMOR app to the AiMOR Calendar device. Follow the steps below for connection:



Download the
"AiMOR APP"
through your mobile
phone




Open the device's
member manage-
ment settings



Open device
sharing



View the device
sharing code



Enter the device
code in the "AiMOR
APP" to bind the
device



You can now
synchronize your
mobile phone with
the calendar


Click on the device(Profiles-Share device) sharing icon"  ", on the Calendar
A pop-up will appear with a unique code, which is valid for 12 hours.

Now, open the AiMOR app on your phone, tap the " + " icon under the device tab, enter the code from the Calendar, and click. Your mobile app is now connected to the photo frame.

Share the Calendar code with friends and family. They can add the Calendar and start synchronizing or creating schedules, household chores, etc., to it. There is no limit to the number of mobile users connected to the Calendar.

Introduction to Functions on Device Homepage:

Main Functions on Homepage





Upload photos

Transmission from mobile to device




Notification




Display:

Supports Automatic brightness settings.




Weather - Set Time Zone

Navigate to Device Settings - General - Weather Location to ensure that the weather positioning is accurate.



Introduction to Main Functional Pages on Mobile App:



Smart Creation, Star Assignment, Reward Creation, Catering Plans: Smart Recipe Creation, Synchronized Import, Member Management, Photo Upload Synchronized Import:



Star Assignment:

Create rewards and set rules together.

When you have collected enough stars, you can redeem our pre-agreed rewards with them! Rewards can be items or a special experience. Rewards are created by parents on the mobile app, and children can view their rewards and progress on the device.



Wi-Fi

Icon  to view the WiFi status,  means that the WiFi signal is strong,  means no WiFi, and icon  to view the server status,  means connecting to the server,  means disconnecting the server.

Factory Reset

Deletes all data from your frame. This will permanently delete all your photos/videos, contacts, and settings.

Help & About

User guide

Opens the quick start guide that is shown during initial setup of the frame.

Check for Updates

Check for available software updates and download/install them on your frame.

Introduction

Thank you for purchasing this Digital Calendar. Before using the Digital Calendar, please read this manual carefully and keep it in a safe place.

The description in this manual is based on the latest information at the time of editing. The actual product you receive may differ slightly from the descriptions in this manual owing to technical updates and production batch differences. We reserve the right to change product specifications and update this information from time to time. For further assistance, please contact our sellers or after-sales team. The final interpretation right belongs to our company.

Digital Calendar | Warranty Rules

Dear Customer, Thank you very much for using our products, Please read the rules carefully.

1. One year warranty.

According to the prescription, the period for protecting to fix our company's Digital Calendar is one year. (From the day when you have the invoice) During this period, any belongs to under normal usage circumstance cause because of the product quality's problem of breakdown, our company will be responsible for giving free maintain.

2. Free maintain won't be given under the following circumstance.

- ⊙ Without Protection to fix warrantees.
- ⊙ The device is out of the warranty period.
- ⊙ The damage caused by customer inappropriate preservation, maintain, or the usage.
- ⊙ The serial number on the back cover is too dim to recognize if it is for our products.
- ⊙ The breakdown caused by the manipulation that hasn't follow the requests of the manual.
- ⊙ The breakdown, row harm or damaged because of the move or drop.
- ⊙ The breakdown and the damage caused by the force majeure.

Digital Calendar | Warranty Rules

- ◎ The breakdown caused careless protection on the way to service center.
 - ◎ The damage caused by the dismantle movement of a non-our-company authorized maintainer.
3. Customer responsibility.
- ◎ Users should take the responsibility of the data safety.
 - ◎ Please back up all your important data before send your Digital Calendar to our service center. Will not take the responsibility of the data missing.
 - ◎ Please record the product model and serial number and inform the after-sales customer service.
Customer Service & Technical Support:
rongjike@outlook.com
 - ◎ Screen is easy-broken accessories, please avoid the damage from drop or crash. Otherwise you should pay the extra fixing fee.
 - ◎ Please carefully check the screen before purchase the Digital Calendar
 - ◎ Reserves all the right for the final explanation.
- Thank you for choosing our product, We will continue to strive to provide better service.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.