





Candle Warmer Lamp User Manual Thanks for your purchase! If you have any problems, pls feel free to contact us.  (Please select 2.4GHz WiFi, 5GHz is not supported) Download Briturn App Download "Briturn" APP from Apple Store or Google Play Store, or scan the QR code.  Briturn APP  Instructions 1. Installation instructions Step 1: Install the bulb. Step 2: Place the bottled candle on the candle warmer lamp base, then turn on the power. Step 3: Turn on the switch and use the candle warmer lamp.  Adjustable height Timer Switch, 8H 4H 2H Short Press: Brightness Increase (4 gear) Long Press: Infinity Brightening Short Press: Brightness Decrease (4 gear) Long Press: Infinity Dimming Short Press: Switch Long Press 5s: Network Configuration 2.Parameters Main Mode: ZJ-LWB0LA1WB-WUS-4K-BT Working environment: -5°C to +45°C (normal operation) Power: 110V 50W Max / 220V 50W Max Power supply: AC85V-235V, 50/60Hz Suitable Phone OS: Android 8.0 / IOS 12.0 or later 3.WiFi Network Configuration Steps ①Network Pairing Mode Activation Press and hold the power key  for 5 seconds. The LED indicator on the controller and the lamp bulb will flash rapidly, indicating the device has entered network pairing mode. (Important Note: Please complete network configuration within 3 minutes after the lamp starts flashing.) After network pairing, the physical controller's light matches the switch state: light on = switch on, light off = switch off. ②How to Connect Smart Device via WiFi? 1. Open your phone Ble, turn on device. 2. Enter "Briturn" app, tap "Add Device" or click "+" at the top right corner. 3. Tap the device on the list, then select your Wi-Fi network, enter the password, done! ③ How to Connect Smart Device via Ble? 1. Open your phone Ble, turn on device. 2. Enter "Briturn" APP, tap "Add Device" or click "+" at the top right corner. 3. Tap the device on the list, then select upper right corner "Ble Local Mode", done! ④ How to Reset the Factory Setting? Press and hold the power key  for 5 seconds. The LED indicator on the controller and the lamp bulb will flash rapidly, which means the factory reset is completed successfully. 4.Timing Indicator Specifications When the APP sets 2H/4H/8H standard timing, the device indicator will synchronize with the APP. For non-standard APP timing: +0-2H: 2H indicator on +2-4H: 4H indicator on +4-8H: 8H indicator on Actual timing duration follows APP settings. 5.Timer Priority: The latest operation (APP or physical button) takes effect. New timing automatically overwrites the previous one. 6.How to Quickly Link to Alexa or Google Assistant? ① When the device connects to WiFi for the first time, a shortcut for pairing third-party smart voice speakers will pop up immediately. Simply tap it to complete quick binding. ② Scan the QR code labeled "instructions" to view the electronic manual. For more information, go to Help Center- FAQs in the APP, or submit your ticket via Get Support.  Method 1  Method 2 More product or App related issues: Pls scan the "instructions" QR code to read the electronic manual. Pls enter the APP "FAQ" to learn more or submit your case via "Support". Due to the continuous update of the APP, the actual operation may be slightly different from the above description, please refer to the latest APP. 7.Special Tips •Do not place the lamp on a surface tilted more than 6°. •Keep out of reach of children and pets to avoid burns and other injuries. •After the candle has been heated 2-3 times under the candle warmer lamp, the essential oil will begin to volatilize. It is necessary to pour off the layer of melted oil on the surface so that the remaining essential oil can continue to volatilize until the candle is fully melted. •Avoid direct sunlight and high-humidity areas. •Remove all plastic protective packaging from the lamp body prior to first use. •Before powering on, verify that the local mains voltage matches the product rated voltage, and inspect the unit for damage. •Do not connect power until full installation is complete. Unplug the unit before moving it. •Operate the lamp under stable voltage only. Fluctuating voltage will reduce bulb lifespan. •Keep the lamp away from curtains, paper and other combustible materials. •Do not burn open candles while the candle warmer lamp is in operation to prevent safety hazards. •The recommended maximum continuous operation time is 4 hours. •Do not touch the bulb housing or lampshade while the unit is running or before it has fully cooled down to avoid burns. •Turn off and unplug the lamp before bedtime to prevent overheating from prolonged operation. •Never plug in or unplug the power cord with wet hands to avoid electric shock hazards. •This product is for indoor use only. •Unplug the power cord if the lamp will not be used for an extended period. •Children under 14 must use the product under adult supervision at all times. •People with amblyopia or astigmatism, as well as young children, shall not stare at the light source for a long time. 8-Suggestions 1. Unplug the unit before wiping or cleaning. 2. Do not clean the lamp with abrasive tools or chemical solvents. 3. Regular cleaning and inspection are advised to extend the product lifespan. 4. Never rinse the lamp body directly with running water. 5. Do not disassemble or modify this product in any way.
--