

封底

封面

2.4 Bluetooth Selfie Function 1. Turn on Bluetooth on your phone 2. Search for “AB Shutter3” and connect to the device Bluetooth signal 3. Hold the Bluetooth remote and press the button to control photo taking /video recording 4. Enables long-distance selfies and group photos without assistance from others  2.5 Tripod Expansion The bottom of the stand is equipped with a standard 1/4 inch threaded interface, which can be mounted directly on a tripod for stable shooting and long recording sessions. 	PRECAUTIONS 1. Non-MagSafe phones must use the adapter metal ring and should be left for 12 hours before use to avoid weak attachment or accidental dropping 2. Do not clamp onto fragile or easily deformed objects, to avoid damaging the device or the mounting surface 3. Keep the Bluetooth remote away from strong electromagnetic interference to avoid disconnection 4. Use a dry cloth for cleaning. Do not allow liquid to enter the device 5. Do not place the device in high-temperature or humid environments, to extend service life FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. FCC Radiation Exposure Statement The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.	USER MANUAL  LX80 TRAVEL STAND Key Selling Points: MagSafe Magnetic Attachment 360° Rotation Bluetooth Selfie Multi-Scenario Mounting	PRODUCT OVERVIEW 1.1 Core Components  - Magnetic Head: supports MagSafe attachment, rotates freely 360°, and fits multiple shooting angles - Reinforced Clamp: opens with the side button; built-in silicone anti-slip pads help prevent slipping and protect the device - Bluetooth Remote: wirelessly controls phone photography for long distance selfies 1/4-inch threaded interface: compatible with tripods - Adapter metal ring: accessory for non-MagSafe phones	1.2 Dimensions  - Folded size: 6.17cm x 4.27cm x 9.55cm - Expanded size: 6.17 m x 4.27 m x 1.5cm INSTALLATION AND USE 2.1 Phone Compatibility Preparation - iPhone (MagSafe models) Attach the phone directly to the magnetic head. No extra accessory is needed. - Other phones (non-MagSafe models) 1. Peel off the adhesive backing from the adapter metal ring 2. Place the ring flat in the center of the back of the phone 3. Let it sit for 12 hours before use so the adhesive can bond completely	2.2 Mounting and Application Scenarios  1. Press and hold the side button on the stand to open the reinforced lamp 2. Align the clamp with a fixed position such as a desk, door frame, or suitcase handle, then release the button to clamp firmly 3. The silicone anti-slip pads will fit automatically to help prevent slipping 2.3 Angle Adjustment The magnetic head supports 360° horizontal rotation and multi-angle tilt adjustment, allowing for switching among portrait, landscape, upward, and downward shooting positions.
--	--	---	--	--	---