


User Manual

Training Collar System



Pls read this entire manual before using this product.

Here Are Some Tips for You!

1. Avoid leaving the collar on the dog more than 12 hours per day. If possible, please re-pose the collar each 1-2h.
2. Dogs should be at least 6 months old before using the training collar.
3. The electric shock mode should always be the last source to use. Always start at the lowest level and work your way up when using shock mode.
4. To assure that it can be easily charged and fits different specifications of charging plugs and voltage in all over the world, there is no adapter in the package. But you can conveniently charge it with the USB outlet of the power bank/computer/car. If charged by adapter, please note the adapter power must be not greater than 5V/1A.
5. Avoid any contact with other metal things while charging with original USB cable.
6. Skin contact is crucial for the shock mode to work effectively. Make sure that the metal prongs directly contact the skin under dog's neck while using shock mode. And adjust the most comfortable collar length for your dogs. It is recommended to keep 1 thumb apart.
7. As for the pairment, The system has matched the remote control to the receiver, and you can open the product and use it immediately. if you paired the receiver with channel A, the remote can only control the receiver if it is set to channel A.
8. Check the dog's neck skin condition every day, if any signs of skin discomfort are found, please stop using it in time until the skin heals.

Table of Contents

Components ----- 2

Overview ----- 3

 Handheld Remote ----- 3

 Receiver ----- 4

Important Safety Information ----- 5

Operating Guide ----- 6

 Prepare the Remote Transmitter ----- 6

 Prepare the Collar-Receiver ----- 7

 Sync Transmitter with Collar-Receiver ----- 8

 Test the Training System ----- 10

 How to find the Best Static Level for Your Dog? ----- 11

How to Use Test Light Tool ----- 12

Fit the Collar-Receiver ----- 13

Troubleshooting ----- 14

General Training Tips ----- 15

Addendum and Upgrading Notes ----- 16

LIMITED 90 DAYS WARRANTY ----- 16

Warning!!!


This product doesn't come with the charger, you can charge it by connecting your phone charger or computer with the USB cable.

Please charge the product with 5V-output charger only!

Warranty loss and charging damage maybe caused by charging with improper charger.


Notes: You can see the output voltage information on the surface of the charger.

COMPONENTS




1 Remote Transmitter


Adjustable Nylon Collar




2 Collar-Receiver




3 Charging Cable




4 Wrist Strap



5 Test-Light bulb



6 Contact Points




7 Conductive Silicone Jacket


(Components **5** **6** **7** refer to Page 12 for more information)

OVERVIEW

Handheld Remote




Screen



OVERVIEW

Receiver



Important Safety Information

This is the safety alert symbol. It is used to alert you to potential injury hazards, Obey all safety messages that follow this symbol to avoid possible injury.

WARNING

WARNING: Indicates a hazardous situation which, if not avoided, could result in serious injury.

Not for use with aggressive dogs, Do not use this product if your dog is prone to aggressive behavior, aggressive dogs can cause severe injury to their owners and others, If you are not sure that this product is right for your dog, please talk to your veterinarian or a certified trainer.

CAUTION

CAUTION: Used with the safety alert symbol, indicates a hazardous situation, which, if not avoided could result in minor or moderate injury.

- Safety during on-leash training, It is vitally important that you and your dog remain safe while learning during on-leash training, Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area, You must also be physically strong enough to restrain your dog when he tries to chase.
- This pet training device is not a toy, keep away from children.

CAUTION



CAUTION: Used without the safety alert symbol, indicates a hazardous situation, which, if not avoided, could result in harm to your pet.

Risk of skin damage, please read and follow the instructions in this manual, proper fit of the collar is important, A collar worn for too long or made too tight on the pets neck may cause skin damage, ranging from redness to pressure ulcers; this condition is commonly known as bed sores.


- Avoid leaving the collar on the dog for more than 12 hours per day.
- Possible reposition the collar on the pet's neck every 1 to 3 hours.
- Check the fit to prevent excessive pressure; follow the instructions in this manual.
- Never connect a leash to the electronic collar; It will cause excessive pressure on the contact points.
- When using a separate collar for a leash, don't put pressure on the electronic collar.
- Wash the dog's neck area and the contacts of the collar weekly with a damp cloth.
- Check the contact area daily for signs of a rash or a sore.
- If a rash or sore is found, discontinue use of the collar until the skin has healed.
- If the condition persists beyond 48 hours, see your veterinarian.

Operating Guide

Prepare the remote transmitter:



Charger the remote transmitter :

1. Connect the charger connector to the charging hole (5V-Output charger only).
2. Plug the charger into a standard outlet.
3. The red light in the transmitter will be on, indicating that charging is taking place.
4. Charge the transmitter at least 2 hours for first charge or until indication that charging is complete.
5. When charging is complete, the red light will turn green, Also the Battery Capacity Indicator will not flash any more.
6. When battery capacity "  " indicator is empty, please charge it asap.
7. If battery is less than 25%, LED signal flashes red light. Less than 2%, LED signal light quickly flashes three times and automatically shuts off. The transmitter enters low-battery protection state.



How to use the remote transmitter :

1. Press any button on the transmitter to activate the device.
2. Press UP/DOWN buttons to adjust the intensity level of vibration or static shock.
 - Long press UP / DOWN for 3 seconds to quick adjust the intensity of Vibration or Static Shock.
 - Short press UP / DOWN to fine tune the intensity of Vibration or Static Shock.
3. Long press the flashlight button for 3 seconds to turn on the flashlight. Short press the flashlight button to turn it off.
4. Long press (Channel & Screen) lock button for 3 seconds to open the safety lock, and transmitter does n't give out any signal. Long press it for 3 seconds again to close the safety lock, and transmitter gives out signal normally. Short press (Channel & Screen) lock button to switch A or B or C or D or A+B+C+D channel.

Operating Guide

5. Tone Button: When it is pressed, the collar-receiver will give a warning beep. (After 10 seconds of long press, the beep will stop automatically)
6. Vibration Button: When it is pressed, the collar-receiver will issue the vibration, vibration levels can be adjusted from 0 to 9 by pressing the UP/DOWN Button. (After 10 seconds of long press, the vibration will stop automatically)
7. Shock Button: When it is pressed, the collar-receiver will issue the shock, static shock levels can be adjusted from 00 to 99 by pressing the UP/DOWN Button, When more than 50 level, warning label will prompt. (After 10 seconds of long press, the static shock will stop automatically)

Prepare the collar-Receiver:



Charge the collar-receiver :

1. Charge the charger connector to the magnetic charging port (5V-output charger only).
2. Plug the charger into a standard outlet.
3. The red LED signal light in the collar-receiver will turn on, The green LED current battery light keeps flashing. (A)
4. Charge the collar-receiver for at least 3 hours for the first charge or until indication that charging is complete.
5. After the receiver has been fully charged, LED battery indicator is off, the LED signal light will turn green. (B)
6. when collar-receiver batter is less than 25%, LED signal flashes red light (charge the battery as soon as possible). Less than 2%, LED signal light, quickly flashes three times, collar-receiver gives out two beeps, automatically shuts off and enters low-battery protection state.

Operating Guide

How to use the collar-receiver :

1. ON/OFF/Encode Button:
 - Short press ON/OFF/Encode Button to activate the collar-receiver.
 - Long press ON/OFF/Encode Button for 3-5 seconds to close the collar-receiver When collar-receiver is off, Long press ON/OFF/Encode Button for 3-5 seconds to enter pairing mode.
2. LED Battery Indicator: Short press the ON/OFF button, the current battery level of the collar-receiver will be displayed (25%, 50%, 75%, 100%).
3. In “standby” status, LED signal light flashes green every 8 seconds. If battery is lower than 25%, it flashes red (charge the battery as soon as possible).
4. When the collar-receiver receives the command from the remote Transmitter, LED light flashes green.

Sync Transmitter with Collar-Receiver:

(Notes: you may skip this step because the set is already paired by factory setting)

1. Activate the remote control, please select the channel to be paired (A or B or C or D or ABCD)

