

Magnetic WireLess Charger Holder

Installation Instruction



We understand your expectations for product quality and service.

- Should you encounter any issues — including missing accessories, damaged components, cannot charge, or even simple dissatisfaction please contact us directly.
- We promise to solve the problem in the fastest and most efficient way within 24 hours.

(Direct contact email:

SMARTSELECTHOMETECH@outlook.com

or contact seller **SMARTSELECT HOMETECH** via the Amazon platform)

Parts List



Compatible Phone Models



Compatible with iPhone 12/13/14/15/16/17 series (including Pro, Max, Plus and Air models), Samsung Galaxy S20/S21/S22/S23/S24 Ultra, and Google Pixel 10 series. It also fits all Android phones equipped with built-in metal rings and MagSafe-compatible protective cases.

⚠ Note: Max output power : 15W.

How to Use the Metal Ring

(for non-magnetic phones.)

The magnetic ring can be installed on extra-thick phone cases.

STEP 1



1. Wipe the back of your phone case with the wet and dry wipe.

STEP 2



2. Remove the protective film from the metal ring.

STEP 3



3. Allow metal ring to cure 6 hours before use.

STEP 4



4. Done! Ready to use.

STEP 3



3. Peel off the red pad.

STEP 4




4. Adjust the angle and position, press and hold for at least 10 seconds, then allow at least 6 hours for the adhesive to cure before use.

STEP 5



5. You can separate the magnetic mount from the magnetic plate and adjust it to your desired angle.

STEP 6



6. Put your phone on the magnetic phone holder.

STEP 7



7. Connect the included charging cable to activate the wireless charging function.

FCC Warning

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.


How to Use the Magnetic Phone Holder

STEP 1



1. Wipe the target area on the laptop with the wet and dry wipe.

STEP 2



2. Attach the magnetic mount to the magnetic plate.

三折页（包心折） 展开:140X210mm 折好:140x70mm

出血位: 3mm

滑面彩色印刷