

Manual instruction

How to use

Turn on: Press and hold the **Center button** for 3 seconds, and there will be an English voice prompt of 'power on'.

Turn off: Press and hold the **Center button** for 4 seconds, and there will be an English voice prompt of 'power off'.

Volume up/down: press **volume +/-**.

Answer/End call: press the **Play/Pause Button** once in ring/call status.

Reject call: press and hold the **Play/Pause Button** for 2 seconds.

Play: press the **Play/Pause Button** once in standby mode.

Pause: press the **Play/Pause Button** once in playing music mode.

Previous/Next: In playing music, press and hold **volume +/-** for 2 seconds.

Gaming mode/Music mode: Quickly click the **Center Button** 4 times.

Change EQ(different sound effect) : Quickly click the **Play/Pause Button** 3 times.

How to connect

1. In off mode, long press the center button for 5 seconds to get the earphone into pairing status with an English voice prompt 'Pairing'.

The earphone will automatically shut down if pairing fails within 5 minutes.

2. Turn on the Bluetooth on your mobile phone, then search the Bluetooth Device Model Number (the number is printed on the package).

Turn on: Press and hold it for 3 seconds.

Turn off: Press and hold it for 4 seconds.

Gaming mode: Quickly click 4 times.

Volume up:
Click once.

Next:
Press and hold for 2s.



Play/Pause:
Click once.

Answer/End call:
Click once in ring/call status.

Reject call:
Press and hold the Button for 2s.

Change EQ:
Quickly click 3 times.

Volume down:
Click once.

Previous:
Press and hold for 2s.

How to charge

Please charge with a low power charger below 5V-1A.

Low battery (the remaining talk time being less than 10 minutes) : there will be an English voice prompt of 'Please charging', The blue light flashes twice every 2s.

Charging: the red light stays on steadily in LED.

Fully charged : the blue light stays on steadily in LED.

Important safety information

Don't remove or replace the Battery including sensitive electronic components, including a battery, and can be damaged or cause injury if dropped, burned, punctured, crushed, disassembled, or if exposed to excessive heat or liquid. Don't use damaged batteries and electronic components.

Disposal and recycling information

Don't treat the product and battery as a household waste or into a fire. When you decide to dispose of the product and its battery, please follow the local environmental laws to handle the battery to avoid an explosion.

Medical device interference

The product contains components and radios that emit electromagnetic fields and also contains magnets. These electromagnetic fields and magnets may interfere with pacemakers, defibrillators, or other medical devices. Maintain a safe distance of separation between your medical device and product. Consult your physician and medical device manufacturer for information specific to your medical device. Stop using product if you suspect it is interfering with your pacemaker, defibrillator, or any other medical device. Please fully charge before use.

Please use a low-power charger below 5V-2A to charge, otherwise it will cause damage to the earphone.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.